

Fuegobird
YOUR GAMING EXPERT

UG-01

USER MANUAL

LED Indicator Light Description

Pairing Status	Blue and red LED blink alternately
Power On	Blue LED blink on continuously to enter the pairing status
Standby Mode	Blue LED blink on intermittently
Low Battery Status	Red LED flashes 6 times in 6 seconds
Charging Status	Red LED blink on while in charging, red LED goes out while fully charged

Headset And Wireless Transmitter Overview



Wireless Headphones Basic Key Operation

Turn On

Long press to turn on the headphones, it automatically enters pairing status after the blue LED starts on for 2 seconds. Wireless indicator light will function alternately between blue and red color.

Turn Off

Long press to turn off the headphones, the red LED starts on for 2 seconds, then goes out.

Volume Adjustment

Turn the volume control knob to the side to turn up the volume, turn it to the side to turn down the volume.

Music Selection

Double click to skip to the next song.
Click three times to skip to the previous song.

Play/Pause/Phone call

Music/Pause: Short press when in music playing.
Music/Pause: Short press when in music pause.
Answer Call: Short press when a call coming in.
Hang up: Short press when on a call.
Refuse to Answer: Double click when a call coming in.

Microphone on and Mute the Microphone

1. Press the button M to control the use of the microphone, the microphone indicator will be off and there will be a voice indicator.
 2. Repeat to using the microphone. In the state of muting the microphone, click the button M to resume using the microphone. The microphone indicator light is on and there is a voice indicator.
- Notes: The use of microphone can also be prohibited/resumed in non-calling state.

Headphone Charging

After in a one battery, please charge it for about 2 hour with USB-C charging cable. The headphones will turn off automatically while charging. Red LED show on indicator while in charging, and red LED goes off while fully charged.

Power Status

When the headphones is connected to the USB device, the current power status of the headphones will be showed on the upper right corner of the device screen.

Low-in Mode

Plug in the audio cable, the headphones will automatically turn off. In this mode, the microphone on the headset can be used for calls.
 Note: In wired use, the headphones cannot be turned on normally, you need to using the audio cable to turn it on normally and use.

Wireless Mode Connection

After the headset is turned on, the indicator light flashes red and blue alternately, turn on the Wireless function of the Bluetooth device, search by the name of the headset (Fuegobird LG-01) and click LG-01 to connect. The blue LED will stay on indefinitely after successfully connected, the blue LED will flash slowly when the headset is pairing.

Wireless Disconnection

In the connected state of headphones and the wireless device, press **M** 3 times continuously, Headphone disconnected.

Auto off and Long-distance Reconnect

The headphones will be disconnected automatically when out of the effective range. When back to effective range within 5 minutes, it will auto-reconnect. The headphones will turn off automatically 3 out of the effective range (out 15) minutes.

Transmitter Mode Connection**Transmitter LED Indicator Description**

Pairing Status	Open and orange LED flashes alternately
Connection Succeeded	Open LED stays on indefinitely
Reconnect status	Open LED flashes slowly

Connect to PC

1. Insert the transmitter into the USB port of the PC, the PC will automatically install the driver, the open and orange LED of the transmitter flashes alternately and automatically enters the pairing state.
2. Long press **M** of the headset for 3 seconds, the headset will automatically enter the pairing state after power on.
3. When the blue LED of the headphones and the open LED of the transmitter both stay on indefinitely, the headphones and transmitter are connected, and you can begin to music, games, video calls calls etc.

Notes: If the headset and transmitter cannot be used, please set LED-01 as a microphone headset and audio-cable device.

Connect to PDA/PS4/PlayPS5

1. Turn on the PDA game console.
2. Insert the transmitter into the USB port of PDA, the PDA will automatically install the driver, and the open and orange LED of the transmitter will flashes alternately and enter to the pairing status automatically.
3. Long press **M** of the headset for 3 seconds, the headset will automatically enter the pairing state after power on.
4. When the blue LED of the headphones and the open LED of the transmitter both stay on indefinitely, the headphones and transmitter are connected.
5. When the LG-01 wireless headphone is detected, it will recognize the "Settings" menu and select.
6. Highlight the "Settings" menu, select and select.
7. Scroll down to "Peripherals" and select.
8. Scroll down to "Audio Device" and select.
9. Set the "Audio Device" to "LG-01" wireless headphones.
10. Set the "Output Device" to "LG-01" wireless headphones.
11. Select "Output to Headphone" and select "All Audio".

Headphones Actively Connect Back to the Transmitter Function

In transmitter mode, the headset will actively reconnect back to the transmitter after turning on.

Enable an active connection between the transmitter and the headset

When the headset is not connected with the wireless device, when the transmitter and the headset cannot be connected, press the transmitter button for 3 seconds or plug and shake the transmitter, the headset and the transmitter connect actively.

Wireless Mode/Transmitter Mode Switch

1. In the mode of Wireless, press the button of M for 3 seconds to switch to transmitter mode. The headset actively connect with the transmitter.
2. In the mode of transmitter, press the button of M for 3 seconds to switch to Wireless mode. The headset actively enter Wireless receiver state of 200MHz center.

Headphone Parameters Information

Wireless Version	Wireless V2.0
Wireless Protocol	Bluetooth 2.0+EDR
Accept Range	6-10M
Resistance	300kΩ
Sensitivity	105dB/1000 at 1KHz
Frequency Range	20Hz—20K Hz
Charging Voltage	5.0V
Charging Current	500mA
Operating Voltage	3.7V
Operating Current	10-20mA

Transmitter Parameters Information

Wireless Version	Wireless V2.0
Input	1.8V
Frequency Range	20Hz—20KHz
Wireless Protocol	Bluetooth 2.0+EDR
Transmission Range	10M
Operating Voltage	3V
Operating Current	10-20mA

Packing List

1. Wireless Headphone	4. User Manual
2. Charging Cable	5. Wireless Transmitter
3. Audio Cable	

Warn. Tip

1. Please charge the headphones with 5V 1A / 5V 2A charger, high-voltage may damage the headphones.
2. When the headphones has not been used for more than 3 months, it needs to be charged before use.

2. When the headphones has not been used for a long time, we suggest you charge every 3 months to avoid good extension for the battery.
3. We suggest you fully charge the headphones for the first time use.

Attention

1. Please keep or use the headphones at normal temperature, avoid direct sunlight.
2. Please keep the headphones away from fire or other hot objects.
3. Please keep the headphones away from open flames or a charged to fluid, acid, etc.
4. Please don't try to use other methods of charging other than the USB charging cable and system.
5. Please don't disassemble, repair, or modify.
6. Please pay attention to excessive shock, if any damage (the device deformation, corrosion, etc.) please turn to us for assistance by the correct information on the warranty card.
7. If the headphones produced at abnormal level, higher than normal temperature, color, or shape change abnormally, please stop using and turn to us for assistance by the correct information on the warranty card.

Warning

Properly use of headphones at high volume may cause damage to your hearing. The device complies with Part 15 of the FCC Rules. The operation must meet the following two conditions:

- (1) This device may not cause harmful interference.
- (2) This device must be accepted by the licensee from other sources, including wireless operation.

WARRANTY CARD

Product Name	Product Code
Purchase Date	Purchase Price
Purchase Location	Name of Dealer
City Name	Phone Number
City Address	

Warranty Description

Please keep this warranty card and your purchase record properly, along with other cards sending the product to dealer. If you can't provide the warranty card or original purchase certificate, the valuation limit of this product warranty will be based on the product insurance rate.

Warranty Regulations

1. If you find any problems during using, please don't hesitate to call immediately to us.
2. Within one year from the purchase date, if the product with quality issue and the technical staff of our company can't determine that the issue caused under normal use, we will provide free replacement service.
3. In the following cases, our company refuses to provide free warranty service, and provide maintenance services, fee of labor parts, only charge for parts:
 - a. The product user can't follow designer's use or incorrect operation, mislight use or incorrect setting.
 - b. The product has been dismantled or repaired without our company authorization.
 - c. The responsible dealer and his user used or kept wrongly, and the damage is determined due to misuse or neglect. The responsible dealer is broken, modified, increased or added, the user is damaged, tampered and used other non-roads damage repair.
 - d. The original warranty card and valid purchase record can't be provided, and the purchase date is beyond the warranty period.
 - e. The free service provided by this warranty card may be closed product improvement, and other decisions, etc.

Product Qualification Certificate

After inspection, the product meets the technical standards and is allowed to leave the factory.

