


# FERM®

Art. no. BCM1020  
BATTERY CHARGER + JUMP STARTER 6V/12V

### STATUS



- CONNECTED
- CHARGING
- CHARGED

### DIGITAL DISPLAY

- BATTERY %
- VOLTAGE
- ALERNATOR %


### BATTERY TYPE

- 12V REGULAR
- 12V DEEP CYCLE
- 12V AGM/GEL
- 6V REGULAR

### CHARGE START


- FAST CHARGE
- NORMAL CHARGE
- START 

### BATTERY CHARGER + JUMP STARTER 6V/12V

<b>Input</b>	230V~ 50Hz, 250W • 400W max.	
<b>Output</b>	Choose Setting	
	6V REGULAR	Normal charge: 6V DC • 2A
	12V REGULAR 12V DEEP CHARGE 12V AGM/GEL	Fast charge: 12V DC • 6A min • 12A max Normal charge: 12V DC • 2A
	ENGINE START	12V DC • 75A max 3s max ON / 180s min OFF)
	Apply to Lead-acid battery: 8Ah - 180Ah	
<b>Warnings</b>	<ul style="list-style-type: none"><li>• Before charging read the instructions</li><li>• For indore use / do not expose to rain</li><li>• Disconnect the power supply before making or breaking the connections to the battery</li><li>• WARNING: Explosive gases. Prevent flames and sparks. Provide adequate ventilation during charging</li></ul>	

  
1X80A

PRESS



AC 230V 50Hz



FERM B.V. • LINGENSTRAAT 6 • 8028 PM ZWOLLE • NETHERLANDS  
WWW.FERM.COM • DESIGNED IN THE NETHERLANDS • MADE IN PRC

Serial no. \_\_\_\_\_

1512-11