






## All Surface Christmas LED Tree 150/200/300 CM

Assembly instructions - Opbouw instructies - Aufbauanleitung - Instructions de construction



1



2



3





# All Surface Christmas LED Tree 150/200/300 CM

Assembly instructions - Opbouw instructies - Aufbauanleitung - Instructions de construction



4



5



6



7



## IMPORTANT

- ⚠ Lower the tree at wind force 6 or higher
- ⚠ Fairybell® kan ook bij windsticht 6 of hoger
- ⚠ Nehmen Sie den Baum bei Windstärke 6 oder höher ab
- ⚠ Sbracciate (consorziate) l'Outdoor Christmas tree con vento forte 6 o superiore

## SPARE PARTS / ONDERDELEN / ERSATZTEILE / RICAMBI

You can easily replace all parts yourself. Visit our website for original spare parts  
Alle onderdelen zijn zelf eenvoudig te vervangen. Bezoek onze website voor onderdelen  
Sie können problemlos alle Teile selber austauschen. Alle Original-Ersatzteile finden Sie auf unserer Website.  
Tutti i ricambi sono facilmente sostituibili. Visitate il nostro sito internet per i ricambi originali.



For more information:

[www.fairybell.eu/service](http://www.fairybell.eu/service)

[www.fairybell.us/service](http://www.fairybell.us/service)