


# 2303 ELECTRIC WATER GUN MANUAL

## Accessories



Water gun range: about 8-10 meters (The water gun cannot be immersed in the water.)  
Water gun capacity: 680ML

## Battery charging, installation instruction



Charging time: 4 hours (the indicator light is on when charging, and the indicator light is off when fully charged)  
Use time: 25 minutes  
Battery capacity: 800mAh

## Water gun suction instructions



Push the trigger forward to absorb water

## Water gun firing



Press the trigger backward to launch

## Increase capacity



Use beverage bottles to increase capacity

## Assembly instructions



Insert the butt into the barrel