



Product name	Outdoor Gas Pizza Oven			UK CA CE	
Model Number	SRGG18003			0554-23 0863-23	
Serial Number	Shinerch Industrial Ltd 8/F, Noble Center No.1006, 3rd Fuzhong Road Futian District, Shenzhen, China			P/N: 1338DN049	
Manufacturer name and Address	134(28-30)(37)	138(P/30)	138(P/37)	138(P/50)	
Gas Category	G30 Butane at 28-30 mbar	G30 Butane and G31 Propane at 37 mbar	G30 Butane and G31 Propane at 37 mbar	G30 Butane and G31 Propane at 50mbar	
Pressure	134(28-30)(37)	138(P/30)	138(P/37)	138(P/50)	
Country Code	134(28-30)(37)	138(P/30)	138(P/37)	138(P/50)	
Heat Input	Main burner: 4.0kW x 1	Main burner: 4.0kW x 1	Main burner: 4.0kW x 1	Main burner: 4.0kW x 1	
Water Size	0.96mm	0.96mm	0.91mm	0.95mm	
Input	4.0kW (G30: 25qph, G31: 261qph)	0.96mm	0.91mm	0.95mm	

Lighting the appliance

1. If the appliance has a lidhood, open it.
2. Ensure all knobs are in the "OFF" position.
3. Open the gas control valve on the gas bottle or regulator.
4. Each control has its own igniter. Push and hold the igniter button for 2-3 seconds. The high position. Hold the control knob pushed down for 2-3 seconds. It will light the burner. After each "click" sound generated by the igniter, turn the knob to "OFF" position and hold it for 5 seconds.
5. If burner fails to ignite after several times, turn control knob to the "OFF" position and repeat the above steps.
6. After the burner is lit, the igniter should be rotated at the high position for 3-5 minutes in order to preheat the plate. This process should be done before every cooking session. The burner is in high position for fast cooking results.

Use outdoors only. Do not use in combustible construction. 100cm clearance from side and back. Accessible parts may be very hot. Keep children away from the oven when using this barbecue. Made in China.