

M027

COFFEE HOUSE



Happiness is a cup of coffee



DIY handmade goods-Happiness is a cup of coffee



NOTICE OF ASSEMBLE



Making tips

1. LED wiring indication:
White=Positive; Grey=Negative.
2. Use a craft blade to carefully skim over the plastic to bare the copper wire.
3. For LED wiring extension, please refer to the below steps:



Twist the copper of both LED wire and extension wire together.



Do the same on the white wire.
Remarks: Tie a knot at the end of the grey wire to differentiate the polarity.




Place the duly twist wire on the tapes provided.



Roll and wrap the wire.



Place another wire next to it.
Remarks: DO NOT contact both copper wire to avoid short circuit.



Roll and wrap it together.

Warnings

- The product is not suitable for children under 14 years old. The should be under custody of adults when playing with the product.
- There are small parts, please do not swallow them for avoiding dangerous accidents.
- Please also pay attention to the sharp-pointed materials to avoid injuries.

Tips for assembling

1. Pictures shown on the package may be slightly different from the actual product.
2. Please use the provided tracing paper for cutting purpose to achieve the best outcome.
3. Product designs and specification may be subject to change without advance notice for purpose of making improvement.
4. Testing on LED function:



DO NOT contact the LED wire end direct to the battery cell.



DO NOT contact the LED wire end direct to the battery cell.

How to assemble the battery holder



1. Material and tools needed:
Battery holder, LED bulb, tape, screw driver and 2 piece AA size battery (not provided)



2. Use screw driver and take the lid off from the battery holder.



3. Insert the battery take notes on the polarity.



4. Connect the red wire to grey wire. Connect the black wire to white wire.



5. Wrap the exposed wire with the tapes.



6. Place the box lid and fastness with screw driver.





Product information



Cabinet



10



6




11



7

Cabinet



3



8



1



4

Coffee machine









9







2

Cake cabinet











50



51



52





53




Books









Chair



Storage shelf







6



11


Potted plant



7



12



1



8

Flower shelf



2



9



1



3




10



2



4



5



6



7



D19



1



2



E12: 3*8cm

E12: 3*6.5cm

D20

D24



1



2



D22

D30

E04: 3cm*2
2.5cm*4
2cm*2

E04: 2.5cm*8



3

E04: 4cm



D25



D18

D27

E04: 2.5cm*8

E04: 3cm*2
2.5cm*6






4







1

The making method are same for other plants, the length of E04, please refer to the above.





Advertising board






Music machine core manual guide
(If you have purchased the music machine core, please fix it firstly)

F01 F02 F03
 *2pcs



How to connect to battery box



14



15



16



17



18



19



20



21



22

Trim all the LED wiring to the same length. Use a craft blade to carefully skim over the plastic base the copper wire. Twist the same colour wire together.



23



1

Twist the following wire together:
(i) BLACK wire from the battery box with the WHITE wire from LED bulb
(ii) RED wire from the battery box with the GREY wire from LED bulb



2

Roll and seal the duly twist copper with the white tape provided. Place the battery box in the allocated space.

Statement: the lamp wires cannot be inserted into the output socket.

- Can use 5 batteries
- Please notice the place of anode and cathode when put in the batteries
- Rechargeable batteries are not blank electricity
- Rechargeable batteries can only be charged under adult supervision
- Rechargeable batteries should be removed from the toy before charging
- Different types of batteries cannot mix; Do not mix new batteries in use with semi-used batteries.
- Run out of battery should be removed from the toy
- The power shall not be short circuit



3



4



1



2



Installation of dust proof cover

(For updated version, the parts need to be purchased separately)




F04
0.15*18*20cm



F05
0.15*18*19cm
*2pcs



F06
0.15*19*18.7cm
*2pcs



1. Tear off kraft paper of each piece of transparent cover.

2. Paste F04, F05, and F06 together to complete the dust proof cover as shown.

Photo of Dust proof cover

