

INSTRUCTION MANUAL



Thank you for purchasing the electronic scale made of micro-computer. For proper use of the product and ensuring its accuracy and service life, please read this manual carefully before using it.

Please pay attention to configuration or connection is different.

Basic Characteristics

- High precision sensor
- Weighting range of 0kg to 50kg
- Display screen 1g
- LED display anti-against light display
- Automatic zero offset
- Overload warning
- Unit conversion function, unit: kg/cm

Power Supply

This product adopts the micro-computer-processor design with auto-charge compensation. The battery is recommended for re-charging. Please handle the product gently when using. If the battery is old, please replace it with a new one. After using, please clean the product, remove the battery, and then replace the battery.

Operation



- Put the weighing plate (scale) on the scale body
- Press the power button to turn on the scale
- No weighing or weighing too heavy, the display will show the display: exceed 50kg

Unit Conversion

This product is designed with two anti-against systems and British standard, which can be converted instantly by pressing UNIT button.

Manual Turn-off

Press UNIT button three times to turn off the scale.

Overload Prompt

When the product has exceeded the weighing capacity, it shows the maximum load exceeds the maximum load. Please take off the object immediately to avoid damage to the scale body.

Low Voltage Prompt

When the battery is low, the low voltage sign will appear on the display for about 30s. At this time, please replace the battery (2AA 1.5V).

Note

- Do not drop the product or expose it to strong impact or chemicals.
- Acknowledgment part of the scale body is cleaned with soft sponge. In addition, a large or other cleaning chemicals please a few of them.
- When weighing, please put the scale on a flat and stable surface. Do not put it on a vibration or a soft surface.