


A80 label Printer Use Manual



App Download and settings

Download

Search the "SharpFox" in app store for IOS and Android as listed below:



Settings

Double-click the power button, the printer will print out the QR code of the bound device; add a device through the App, scan the QR code to connect to the printer

Note: Do not search for Bluetooth printer connection in the Bluetooth settings of the mobile phone.

Contents

02.....	Packing list
03.....	Specifications
04.....	APP Connection
05.....	File print
06.....	Windows - Printer Driver Installation
07.....	Windows Printing Note
08-09.....	Mac - Printer Driver Installation
11.....	Mac Printing Note
12.....	LED Status
13.....	Maintenance
14.....	Safty notices

Packing list



Printer



USB Cabel



Use Manual

2

Specifications

Model: A80

Printing method: thermal

Resolution: 200dpi & 300dpi

Speed: 10mm/s

Width: 57-216mm

Interface: USB/Blue-tooth

Size: 290*90*60 mm

Product net weight: ~756g

Print Head

cardboard
buckle


Type-C

Paper bin lid
switch



3

APP connection




Note:

1. Turn on phone Bluetooth;
2. Open APP Click to search for Label Printer.

4

File print



1) The default size is shown here: 210mm, if you use other sizes of stickers, please select the correct size.

2) Documents Printing: import files from other APPs - Word, PDF, Txt.

3) Picture printing - import pictures from mobile phone album.

4) Scan printing - take pictures of the scenes that need to be printed - adjust - print.

5


Windows - Printer driver installation

Note: Before installing the driver, turn off your computer antivirus software. The printer needed to be connected to the power supply and computer, and the power on state.

1.USB inserted into the computer, will automatically pop up the folder, double-click the compressed package to install.

AB0-Printer-Driver-Setup v1.0.0

Double - Click



AB0-Printer-Driver-Setup v1.0.0



NOTE: Before selecting USB, please make sure that the power supply of the machine is connected and the machine is turned on.



NOTE:

- 1.If you use PDF , Word, Txt to print directly, you need to select the corresponding printer driver **A80H**.
- 2.the paper size is selected according to the actual paper size used, set the number of copies,
- 3.click print.

Mac - Printer driver installation




Note: Before installing the driver, turn off your computer antivirus software. The printer needs to be connected to the power supply and computer, and the power on state.

1. USB inserted into the computer, will automatically pop up the folder, double-click the compressed package to install.




8

Mac - Printer driver installation




9

The driver installation is complete - select the correct size and printer while printing. Select the file or picture you need to print.



Name: A80



NOTE:
Choose the correct size.)

LED Status

Light state	Description	Troubleshoot
Green light always on	Normal operation	
Slow flashing green light	Charging when printer turned on	The green light always on when fully charged
Flashing red and green lights alternately	Print head overheating	Printer will automatically resume once the printer head has cooled down.
Red light always on	a、Charging in shutdown state b、Top cover open c、No paper	a、When fully charged, the light turns green. b、Close the top cover correctly. c、Load paper correctly
Blue light flashing	Bluetooth is initializing	Please wait for Bluetooth initialization to complete before linking
Blue light always on	Bluetooth is already connected	

Maintenance

1. Turn the printer off, remove the power cord, and open the cover.
2. Wait until the printer head cools down.
The printer head may be very hot after printing.
3. Completely clean printer head using an alcohol swap (not water).
4. Wait until the alcohol has completely vaporized, then close the cover.
5. Connect the power cord and print a test page to check if it is clean.

NOTICE

Ensure power is off when performing maintenance.

PRO TIPS

Avoid using poor quality labels as they can damage the printer. Regularly clean the printer head.

If paper is jammed, turn off the printer, and allow the printer head to cool down. Open the cover and ensure that the rubber is clean. If dirty, use alcohol to clean. Allow the area to dry off before turning the printer on.

Insert this printer into the same USB port on your computer every time. This will avoid creating duplicate copies of the printer in your operating system.

Safety notices

The printer head can become very hot after printing labels. Do not touch the printer head.

Do not bend the power cord excessively or place objects on the cord.

Do not use the printer if you find any irregularities as these could result in fire or electrocution.

Keep the printer out of reach of children.

Use only approved accessories and do not try to disassemble or repair the unit by yourself.

Keep the printer away from water and other objects that could penetrate the components.

Please unplug the printer when it is not in use for long periods of time.

After-sales Service Email: marklifeservice@gmail.com