
# Bloom Mixer



## Product parameters

Body size: 22,5\*3cm Body weight: 80g

Package size: 8\*8\*26cm

Battery: 2pcs AA batteries Speed:  $10000 \pm 10\%$  rpm Motor power: 1.5-2.5W

Output voltage: DC3V 0.5A
Endurance time: About 2 hours (idling time)

Main material: ABS (fuselage)

# Product standard configuration

Whisk x1

Instructions x1

The battery is not included in the matching, so you need to buy it yourself.

## Usage method

#### 1. Install 2 No.5 AA batteries






Note: first install the battery with "+" upward and then "+" downward. If it is installed reversely, it will not work normally.

2. Press the button to use and release to close.



# Product size





# Maintenance tips

#### Clean:

- 1. Please clean with a soft cloth and do not use a brush to avoid abrasion marks.
- 2. Do not soak for a long time. Wipe dry with a cloth after washing.

#### Preservation:

- 1. When the stainless steel mixing head is idle everyday, try to keep it dry.
- 2. Take out the battery if you don't use it tor a long time.

### **Operation Skills:**

- 1. The milk should not exceed one-half of the container to avoid spilling when being sent.
- 2. It is recommended to control the passing time within 10s-15s

## Use attention

- 1. Please read this manual before use and keep it properly. Before use, please confirm that the product is not damaged or loose and the mixing rod is not bent before useuse.
- 2. This product is suitable tor the stirring of egg liquid and the foaming and stirring of milk and other liquids. It is a kitchen auxiliary tool tor ordinary families. Please do not use it tor other purposes. Please do not use hand or face close to the rapidly rotating mixing rod to avoid danger and injury.
- 3. Please keep this product out of the reach of children.
- 4. Please do not use this product on an unstable console.
- 5. Please hold the product firmly during use, and do not let the rotating mixing rod contact the container during use.
- 6. Please note that the power must be turned on and off when the mixing rod is in the stirred liquid.
- 7. Please do not apply external force to this product, which will causa damage or damage to this product.
- 8. If this product is damaged or deformed, please do not repair or modify it without authorization, and please stop using it.
- 9. Please do not let children use it alone.