03 Installation-Macbook

**My Microphone is plugged in, but I am not able to see or hear level.- Things to check:**

1.Is the Microphone connected to a native USB port? Hubs will not provide the appropriate current power the Microphone (For USB Microphone)

2.Is the Microphone selected as the default input device in both the system and the software preferences? Also make certain you have an adequate amount of volume set.

3.Does the recording software I am using support a USB input?

My Microphone sounds like it's really far away from me .I am hearing lots of room noise.

-This sounds like your onboard mic is use. Check both system and software references to ensure that microphone is the default input device.

Do I need any special software to use the Microphone?
Do I need any driver?

-Technically, no depending on your application, your OS may have sufficient features to utilize the capabilities of the Microphone.