

SUP ELECTRIC AIR PUMP

NOTE

- Children shall be kept far away from this product and wire.
- The applied power source must be the 12V DC power source
- Don't make the air pump work for more than 15 minutes, because that motor overheating may cause internal damage; and the air pump shall be fully cooled for 30 minutes after continuously working up to 15 minutes.
- This product shall not be exposed to the rain or immersed in water.
- In order to prevent risk, the inflation inlet shall not be forward to face or body.
- Please store it in the dry and ventilated place.
- Don't pull out the hose when inflating, because that the high pressure may hurt the physical body.
- Don't block the air inlet at the bottom of the air pump, and guarantee air inlet to be always unblocked.

