


Step 1


Disconnect your old router, if it's separate from your modem.

Restart your modem by unplugging it and plugging back in.



Connect your Linksys Router. Plug it into power, and connect it to your modem with the provided Ethernet cable.

Give your Router a minute to start up. The light will go from blue to solid white when it connects to the internet.



Seeing a red light?

This means no internet is detected.

1. Make sure all cables are firmly snapped into place.
2. Make sure you disconnected your old router.
3. Your ISP may require resetting your modem. Unplug your modem, wait 3 minutes, and plug it back in.

Seeing a blinking red light?

The Router has internet, but the Node is unable to find its signal.

1. It may be too far away, move it closer.
2. It may be placed in a spot blocking the signal. Keep it out in the open vs closed off or behind furniture.


Seeing a red light?

No internet is detected from the Router. Go back to step 1 and establish an internet connection.

Step 2

Plug in the Mesh Nodes. Keep the Router and Mesh Nodes 1-2 rooms apart and out in the open to receive good Wi-Fi signals.

Restart your modem by unplugging it and plugging back in.



Save this guide for future reference. Your default Wi-Fi Name and Password are also printed on the bottom of your Router.


Step 3

Scan the QR code to connect to your Wi-Fi. That's it! Start using the internet.

Restart your modem by unplugging it and plugging back in.



The light will go from blue to solid white once it connects to the internet.



Visit www.myrouter.info

- Personalize your Wi-Fi name

- Enable Guest Wi-Fi

- Block malicious content with SafeBrowsing

- **Automatically track your warranty**

If you factory reset your Router and Mesh Nodes, the Linksys app is required to set them up.