Extended proaramming Buttons on the back

The extended button can be set as a required shortcut commonbutton to start a certain button operation function by customizing the button combination, so that the operation is more convenient and fast, and the game button is released more quickly

