

ENLARGEMENT  
SYSTEM

# PENIS PUMP

1. Press and hold the power button to turn on/off, single press, and the ricochet starts to work. Press repeatedly to adjust the vibration frequency.

2. "+" adjusts the suction power. Gear 1, 2 and 3 are for long suction while gear 4, 5 and 6 are to release the suction. The maximum negative pressure is 55KPA.

3 The "-" key is the pause and air release key. Press once to pause the air extraction and enter the pressure maintaining state. Press again to release the air in the cup.



Mystease by Tokomundo  
Ohmweg 29  
2952 BB Alblasserdam



## SIMPLE OPERATION

FOR EASY AND  
TIME-SAVING  
USAGE



**Switch/frequency Button**  
Long-press this button for 1.5s to turn the product on or off



**Pump Button**  
After startup, short press this button to enter pump mode, 6 modes in total



**Pause/Deflating Button**  
In the pump mode, short-press this button to pause pumping, short press again to deflate until the air pressure goes back to 0



# PENIS PUMP

ENLARGEMENT  
SYSTEM




Body-safe Sillicon

Healthy & Harmless

Stronger Harder

# 3

CHOOSE THE  
PROPER LEVEL  
ACCORDING TO  
YOUR SPECIFIC  
NEEDS



## WARM NOTICE

Recommended to use  
water-based lube only

Silicon-based lubes will cause  
dissolution reaction