











INSTRUCTION MANUAL



Arthur HL 47 Black
105966

<p>1.</p> 	<p>2.</p> 	<p>3.</p> 
<p>4.</p>  <p>INPUT: AC220-240V~50Hz</p>	<p>5.</p> 	<p>6.</p> 
<p>7.</p> 	<p>Overall Sizes:</p> 	

FittinQ B.V.

Smaragdweg 52, 5527 LB Hapert, The Netherlands
www.qazqa.nl

QAZQA