

*BaByliss***PRO**[®]



ITALIA BRAVA PROFESSIONAL LUXURY DRYER

Instruction/
Styling Guide

Model: BABFB1BA
BABFB1A

IMPORTANT SAFETY INSTRUCTIONS

WARNING

- When using electrical appliances, especially when children are present, basic safety instructions should always be followed.
- Polythene bags over product or package may be dangerous. To avoid danger of suffocation, keep this wrapper away from babies and children. This bag is not a toy.



DANGER

- Do not use this appliance in or near bathtubs, showers, basins or other vessels containing water.
- Do not immerse the appliance in water or other liquids.
- When the hairdryer is used in a bathroom, unplug after use since the proximity of water presents a hazard even when the hairdryer is switched off.
- Do not reach for an appliance that has fallen into water. Unplug immediately.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.



- Children should be supervised to ensure they do not play with the appliance.


IMPORTANT!

- Always unplug the appliance when not in use or before cleaning. Do not leave unattended when plugged in or switched on. Do not place on any heat sensitive surface and always allow to cool before storing away.
- Use this appliance only for its intended use and as described in this instruction booklet.
- Do not use any other attachments other than those supplied with this product.
- Take care to avoid contact between the hot surfaces of the unit and the skin, paying particular attention to the face, neck and hands.
- To prevent the risk of injury, never look directly into the airflow of the appliance when in use.
- Never drop the appliance or insert any object into an opening.
- Never use while sleeping.
- Never block the air openings of the appliance or place on a soft surface such as a bed or couch, where the air openings may be blocked. Keep the air openings free of lint and other debris.
- Do not use outdoors or operate where aerosol (spray) products



are being used or where oxygen is being administered.

- Keep the cord away from heated surfaces.
 - Do not use an extension cord with this appliance.
 - Do not use if the supply cord is damaged. In the event of damage, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
 - After use do not wrap the cord around the appliance as in time this may cause the cord to fracture. Coil cord loosely by the side of the appliance in storage.
 - Always ensure that the voltage to be used corresponds to the voltage marked on the unit.
 - For additional protection, the installation of a residual current device (RCD) with a rated operating current not exceeding 30mA is advisable in the electrical current circuit supplying the bathroom. Ask your installer for advice.
- 
- 



**Professional luxury engine
MaxlifePRO technology
FERRARI designed engine
BABFB1BA- BABFB1A**

FEATURES

- Fully balanced, ergonomic design
- Accelerator for instant turbo drying (1)
- Ferrari designed engine with MaxLife™ PRO brushless technology (2)
- Powerful 2400 watts
- Very long life, up to 10,000 hours
- Central ion generator (3)
- 6 speed and temperature settings (4)
- Cold shot button (5)
- 2 ultra-thin nozzles (6)
- Removable rear filter (7)
- 2.8m tangle-free power cord (8)
- Hang ring (9)
- Diffuser (10)
- Lightweight

MAXLIFE™ PRO TECHNOLOGY

The ItaliaBrava™ dryer is equipped with a Ferrari designed engine, featuring MaxLife™ PRO brushless technology.

Conventional styling tool motors require carbon brushes to operate. Friction eventually wears them down and the motor fails. MaxLife™ PRO technology eliminates the brushes, producing a lighter weight motor that lasts longer – up to 10,000 hours. Rare-earth magnets create an efficient and long-lasting power source within the engine. Sealed ball

bearings reduce vibration and help extend the life of the engine. The ItaliaBrava™ also features a lock-in turbo button, located at the back of the handle. This provides up to a 10% increase in airflow for maximum drying power, and should be used for targeted drying/styling. Simply press the button once to engage the turbo feature for drying hair that is very wet, or for straightening very curly, resistant sections. Press the button again to return to normal high-speed setting.

DRYING BASICS

1. Shampoo and condition hair. Rinse thoroughly. Towel-blot hair to remove excess moisture. Section hair. Using the dryer along with a styling brush, direct hot air through a section of hair at a time. Move dryer steadily across each section so that the hot air passes through hair. Direct airflow at hair, not scalp.
2. Keep dryer's air intake vents unobstructed and free from hair while drying.
3. To avoid over-drying and possible damage to hair or skin, do not concentrate heat on one section for any length of time. Keep dryer moving as you style.
4. When using the dryer to create curls and waves, dry hair almost completely on a warmer temperature setting, then finish styling with cooler air.

5. This dryer includes concentrator attachments. Use the attachments when you need drying power in a small area (such as a curl or a wave), or when you want to relax curly hair.

WARNING

This professional dryer is equipped with a cold air setting, as well as a cold shot button. Do NOT use with the air inlet against hair, or damage will be caused to internal parts.



Never block the air openings of the appliance. Keep the filter intake free of buildup from lint, hair and other debris by cleaning regularly. Allowing the filter to become blocked will decrease performance, shorten the life of the dryer, and risk voiding the warranty.

NEGATIVE ION GENERATOR

The BaBylissPRO™ ItaliaBrava™ hair dryer has a central negative ion generator that generates an exceptional volume of millions of ions per cm³. Hair is naturally

positively charged; this positive charge is increased during drying and generates static electricity, which causes the scales of the hair to move away from each other. The surface of hair thus becomes rough and takes on a lifeless appearance.

The negative ions generated by this hair dryer will neutralize the positive charge and, in this way, remove any static electricity in the hair. Hair is shiny and easy to style. It has been proven that ionic technology acts as a catalyst for hair products.

LIGHTWEIGHT AND ERGONOMIC

The BaBylissPRO™ ItaliaBrava™ hair dryer has an ergonomic handle that makes it very comfortable to use. Its light weight and ideal balance make it perfect for the salon.

CONCENTRATOR NOZZLES

The BaBylissPRO™ ItaliaBrava™ hair dryer comes with 2 different concentrator nozzles:

- one straight, narrow 60mm nozzle that is perfect for straightening because it lets you achieve the required tension on the hair.
- one beveled, large 70mm nozzle for smoother blow-drying; it is slightly diagonal in shape, hugging the shape of the brush perfectly.

USER MAINTENANCE

Your dryer is virtually maintenance free. No lubrication is needed. The dryer must be kept clean for proper operating performance. When cleaning is needed, unplug the cord, allow to cool and clean dust and lint from air intake openings with a small brush or the brush attachment of a vacuum cleaner. The outer surface of the dryer should be wiped clean with a cloth only.

Blocked or clogged air intake vents will cause the dryer to overheat. If overheating occurs, an automatic safety device will shut the dryer or the heat off to prevent damage or personal injury. If the unit or the heat cycles off, turn the dryer off, unplug the cord, and allow the dryer to cool for 10 to 15 minutes before restarting. Make sure air vents are clean, by following below steps.

1. Remove intake filter from back of dryer by twisting counterclockwise.
2. Reach through opening, and press the mesh screen to release it from the filter (Fig. 1).
3. Visually inspect the filter to make sure no hair is caught (Fig. 2). Rinse the mesh screen **ONLY** under running water to clear any debris. Repeat as needed, or use a stiff bristle brush for any difficult build-up.
4. Make sure the mesh screen is free from any debris and completely dry. Place screen into bottom part of removable intake filter (Fig. 3).

5. Press with your finger around the edge of the screen to lock mesh screen in place (Fig. 4).



TWO YEAR WARRANTY

The warranty may only be claimed where proof of original purchase is presented, i.e. original purchase receipt or invoice. We recommend attaching a copy of your purchase receipt to this instruction book and storing in a safe place.

To make a warranty claim you can return the defective product back to the place it was purchased where it will be replaced (see point 12 in conditions). For advice with regard to the warranty claim process please call Customer Service on the phone number below or email conairprofessional_australia@conair.com Trade purchasers (who have purchased from us directly) should contact us directly with regard to warranty claims, either your Conair Sales representative or Customer Services.

Please have the following details to hand:

1. Date of purchase
2. Details of where the product was purchased
3. Product Name/Model Number
4. Confirm you have your purchase receipt
5. Detail the problem with your product

Conair Australia Pty Ltd

PO Box 146
Terrey Hills
NSW 2084

Customer Service Customer Service

Australia: 1800 126806
New Zealand: 0800 003618
email : conairprofessional_australia@conair.com

WARRANTY AGAINST DEFECTS A. AUSTRALIAN CONSUMER LAW

1. Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.
2. The guarantees under the Australian Consumer Law ("ACL") are provided in sections 51 to 59 inclusive of the ACL ("Statutory Guarantees") and the remedies are provided in sections 259 to 266 inclusive of the ACL ("Statutory Remedies").
In New Zealand our goods come with a guarantee that cannot be excluded under the Consumer Guarantee Act 1993.

B. BaByliss PRO EXTENDED WARRANTY

1. In addition and subject to the Statutory Guarantees and Statutory Remedies, the

following express warranty ("Warranty") commences from the date of purchase and continues for a period of **24 months** ("Warranty Period") after which it expires. Subject to the conditions in Section C below, Conair warrants to the original purchaser ("Purchaser") of the BaByliss PRO product that is the subject of this warranty ("Product") that if during the Warranty Period, the Product suffers from any defect caused by faults in materials or workmanship, Conair will a) replace the Product, or b) exchange defective parts in the Product or c) repair the Product, as Conair may choose in its discretion ("Warranty"). In this Warranty "Conair" means Conair Australia Pty Limited (ABN 64 068 492 044) of The Equinox Centre, Suite 101, 18 Rodborough Rd, Frenchs Forest, NSW, 2086. in relation to Products purchased in Australia and Conair New Zealand Ltd in relation to Products purchased in New Zealand.

2. To honour the Warranty, Conair must replace, or exchange parts in, or repair, the Product, as Conair determines, in accordance with paragraph B1 above, subject always to the conditions in Section C below.
3. If any of the conditions in Section C below are inconsistent with any provisions of the ACL or regulations made there under,

those provisions of the ACL or regulations shall prevail to the extent of the inconsistency.

C.CONDITIONS

1. The Product must be used in accordance with manufacturer's instructions. This Warranty does not apply should the defect in or failure of the Product be attributable to misuse, abuse, accident, act of God such as lightning, or nonobservance of manufacturer's instructions on the part of the user. This Warranty does not cover ordinary wear and tear in the Product or its parts.
2. Conair does not accept liability for a) any loss or damage however suffered, caused by or arising out of any failure to use the Product in accordance with the manufacturer's instructions, and b) any indirect, consequential or economic loss or damage however caused.
3. This Warranty is immediately void if – a) any serial number or appliance plate is removed or defaced, b) the Product has been serviced or otherwise repaired by a person not authorized to do so by Conair or where non approved replacement parts are used.
4. The Product must be connected to the electrical voltage supply as specified in the ratings label located on the Product. This Warranty does not cover defects

arising from non-domestic use or incorrect voltage supply.

5. This Warranty may only be claimed against where proof of original purchase is presented, for example, original receipt or invoice.
6. Any parts of the Product that need to be replaced, or if the whole Product needs to be replaced, the replaced Product, become the property of Conair. The Warranty on any replacement Product or parts will expire on the same date that the Warranty Period on the original Product expires.
7. The benefits provided by this Warranty are in addition to all other rights and remedies in respect of the Product which the Purchaser has under the ACL, and applicable laws in New Zealand, which rights and remedies by law may not be excluded. All other warranties and representations express and implied are hereby excluded.
8. The defect must have occurred during the Warranty Period and Purchaser bears the onus of proving that fact, and that the defect was not caused by any of the causes excluded from this Warranty.
9. This Warranty does not cover Products purchased from any person who is not a retailer serviced by Conair's authorized distributors or purchased second hand.

10. The Purchaser is responsible for all postage and freight charges and any other expenses incidental to claiming against this Warranty.

11. The Warranty excludes consumable items (such as blades or brushes) and normal wear and tear.

12. If you're certain your product is defective, and the product is covered by the terms of this warranty, you need to take the product back to the place you purchased it from, where the retailer will replace the product for you on our behalf. In this event, per the terms of this warranty you will need to present this portion of the warranty information and the purchase receipt as proof of purchase so please make sure you keep both these instructions and your receipt on hand for the duration of the warranty period.

SPARE PARTS

Replacement parts may be available for your product. Contact us on the phone or email address provided for more details. Please provide your product name/model number details, date of purchase and part you require.





BaBylissPRO

QUESTIONS OR ADVICE?

Get more from your styling tool,
visit **www.babylisspro.com.au**
and keep up to date with news,
trends, styling tips and much more.

©2016 BaByliss PRO
Conair Australia Pty Ltd
Suite 101, 18 Rodborough Rd,
Frenchs Forest NSW 2086, Australia

Customer Service Hotline:

Australia 1800 126 806
New Zealand 0800 003 618

Customer Service e-mail:

babylisspro_australia@conair.com