

Gigaset

CL390 - CL390 A

You can find the most up-to-date
user guide at
www.gigaset.com/manuals



Contents

Overview	4
Safety precautions	7
Getting started	8
Package contents	8
Base	8
Handset	9
Using the phone	11
Switch the handset on and off	11
Lock/unlock the keypad	11
Control key	11
Display	12
Menu navigation	13
Making calls	14
Making a call	14
Accepting a call	15
Handsfree mode	15
Muting	15
Making internal calls	16
Calling Line Identification	17
Automatic network provider selection (preselection)	18
Call/message lists	19
Call list	19
Message list	20
Directory	21
Local answer machine (if available)	23
Setting up the answer machine	23
Operation using the handset	24
Operation when on the move (remote operation)	26
Assigning key 1	26
Network mailbox	27
Entering a number	27
Playing messages	27
Additional functions	28
Alarm clock	28
Baby monitor (Room monitoring)	29
ECO DECT	30
Protection from undesired calls	31

Extending the functionality of the phone	32
Multiple handsets	32
Repeater support	33
Operating the base on a router/PABX	34
Phone settings	35
Date and time	35
Country and language (if available)	36
Display	36
Tones and signals	37
System	39
Service (Customer Care)	40
Warranty certificate for Switzerland	41
Manufacturer's advice	42
Authorisation	42
Data protection	42
Environment	42
Care	43
Contact with liquid	43
Technical data	44
Character set tables	45
Menu tree	46
Index	49



Not all functions described in the user guide are available in all countries or from all network providers.

Base



Registration/paging key
Locate a handset (paging)
Registering handsets

- ▶ Press **briefly**
- ▶ Press and **hold**

Warranty certificate for Switzerland

The consumer (customer) is covered by a durability warranty against the vendor without prejudice to his claims for defects and under the following conditions:

- New devices and their components in which a defect is detected within 24 months from the date of purchase resulting from a manufacturing and/or materials fault will, at the customer's discretion, be exchanged free of charge for a technologically current device or repaired by Gigaset Communications. For wearing parts (such as batteries, keypads, casing, small casing parts and protective covers as included in the delivery), this guarantee of durability applies for six (6) months from the date of purchase.
- This warranty does not apply in the event a defect to devices is attributable to improper treatment and/or a failure to follow the operating guides.
- This warranty does not cover any services provided by the appointed dealer or the customer itself (such as installation, configuration and software downloads). Manuals and, where applicable, accompanying software on a separate data carrier are also excluded from the warranty.
- Proof of purchase with date of purchase is required as evidence of a valid warranty. Warranty claims must be asserted within two (2) months of the awareness of a warranty event.
- Replaced devices or their components returned to Gigaset Communications during the course of an exchange are transferred to the ownership of Gigaset Communications.
- This warranty applies for new devices purchased in Switzerland. The warrantor is Gigaset Communications Schweiz GmbH, Bielstrasse 20, 4500 Solothurn, Switzerland.
- No further or different claims arising from this manufacturer's warranty will be accepted. Gigaset Communications accepts no liability for operational interruptions, loss of profit and loss of data, software additionally installed by the customer or other information. The customer is responsible for safeguarding these. The disclaimer does not apply if liability is mandatory, for example under the Product Liability Act, in cases of wilful intent, gross negligence, and as a result of loss of life, limbs or health.
- Successful assertion of a warranty claim does not extend the term of the warranty.
- Unless there is a warranty event, Gigaset Communications reserves the right to charge the customer for an exchange or repair. Gigaset Communications will inform the customer of this in advance.
- Gigaset Communications reserves the right to have its service work carried out by a subcontractor. Refer to www.gigaset.com/service for the address.
- Any change to the rules governing burden of proof to the detriment of the customer is not connected with the above rules.

To redeem a warranty, please contact our hotline (Tel. 0848 212 000).

Manufacturer's advice

Authorisation

This device is intended for analogue phone lines in Switzerland.

Country-specific requirements have been taken into consideration.

Hereby, Gigaset Communications GmbH declares that the radio equipment type Gigaset Box 90(A) - Gigaset CL390H is in compliance with Directive 2014/53/EU.

The full text of the EU declaration of conformity is available at the following internet address:
www.gigaset.com/docs.

This declaration could also be available in the "International Declarations of Conformity" or "European Declarations of Conformity" files.

Therefore please check all of these files.

Data protection

We at Gigaset take the protection of our customers' data very seriously. It is precisely for this reason that we are ensuring all our products feature "Privacy by Design" as standard. All information we collect is used to make our products as good as possible. In the process, we ensure your details are protected and only used for the purposes of making available to you a product or service. We know which path your data takes through the company and ensure this happens in line with data protection specifications in a secure and protected manner.

The full text of the privacy policy is available from: www.gigaset.com/privacy-policy

Environment

Our environmental statement

We at Gigaset Communications GmbH are aware of our social responsibility. That is why we actively take steps to create a better world. In all areas of our business – from product planning and production to sales and waste of disposal – following our environmental conscience in everything we do is of utmost importance to us.

Learn more about our earth-friendly products and processes online at www.gigaset.com.

Environmental management system



Gigaset Communications GmbH is certified pursuant to the international standards ISO 14001 and ISO 9001.

ISO 14001 (Environment): Certified since September 2007 by TÜV SÜD Management Service GmbH.

ISO 9001 (Quality): Certified since 17/02/1994 by TÜV SÜD Management Service GmbH.

Technical data

Batteries

Technology:	Nickel metal hydride (NiMH)
Size:	AAA (Micro, HR03)
Voltage:	1.2 V
Capacity:	400 - 1000 mAh

Handset operating times/charging times

The operating time of your Gigaset depends on the capacity of the battery, its age and the way it is used. (All times are maximums).

Standby time (hours)	180 / 110*
Talktime (hours)	12
Operating time for 1.5 h of calls per day (hours)	90 / 70*
Charging time in charging cradle (hours)	4.5
Charging time in base (hours)	5

* **No Radiation** switched on/off, without display backlight in idle mode

Power consumption of the handset in the charging cradle

When charging:	approx. 2.10 W
To maintain the charge status:	approx. 1.30 W

Base power consumption

Without answer machine

Standby:	
• Handset in the charging cradle (charging)	approx. 2.00 W
• Handset in the charging cradle (sustained charge)	approx. 0.60 W
• Handset away from the charging cradle	approx. 0.55 W
During a call:	approx. 0.65 W

With answer machine

Standby:	
• Handset in the charging cradle (charging)	approx. 2.80 W
• Handset in the charging cradle (sustained charge)	approx. 1.00 W
• Handset away from the charging cradle	approx. 0.65 W
During a call:	approx. 0.75 W

Index

- A**
- Accepting a call 15
 - Adjusting the call volume (handset) 37
 - Adjusting the ringtone melody (handset) 37
 - Answer 15
 - Answer machine
 - actions during playback 25
 - announcement 23
 - enabling and disabling 24
 - listening to message 24
 - operation from the handset 23
 - recording time 23
 - remote operation 26
 - time to call accept 23
 - Answer machine list 20
 - Assistant for set-up 10
 - Authorisation 42
 - Automatic network provider
 - selection 18
- B**
- Baby monitor 29
 - activation 29
 - deactivation 29
 - Backlight 36
 - Base
 - connecting to the mains power supply/telephone network 8
 - connecting to the router 8
 - restore to defaults 39
 - Battery
 - charge level 13
 - charging 9
 - insert 9
 - recommended batteries 44
 - Black list 31
 - Broken display 7
- C**
- Calendar, Persian 35
 - Call
 - external 14
 - internal 16
 - Call list 19
 - copy a number to the black list 31
 - functions 20
 - opening 20
 - set the list type 19
 - Calling
 - external 14
 - internal 16
 - Calls
 - making an external call 14
 - transferring (connecting) 16
 - Cancel the alarm (baby monitor) 29
- Care** 43
- Care of the device 43
 - Change the recording time 23
 - Changing the call volume
 - during a call 14, 37
 - permanently 37
 - Changing the display language 36
 - Character set (handset) 45
 - Charging time of handset 44
 - CLI, Calling Line Identification 17
 - CLIP, CLI Presentation 17
 - CLIR, CLI Restriction 17
 - Connecting 16
 - Connecting the charger cradle 9
 - Connecting the power cable 8
 - Consultation call (internal) 16
 - Contact with liquid 43
 - Control key 4, 11
 - accessing display functions 12
 - Country 36
 - Customer Care 40
- D**
- Data protection 42
 - Date and time
 - accept 35
 - set 35
 - Dialling mode 34
 - Directory 21
 - assign quick-dial key 22
 - delete 22
 - opening 21
 - saving the first number 21
 - selecting an entry 21
 - sending entry/list to handset 22
 - VIP contacts 21
 - Directory entry
 - delete 22
 - Disabling
 - answer machine 24
 - Disabling wireless module 30
 - Display
 - adjust contrast 36
 - anonymous 17
 - broken 7
 - disable new messages 19
 - external call 17
 - icons 6
 - large dial keys 36
 - phone number (CLIP) 17
 - unknown 17
 - Display backlight 36
 - Display functions 12
 - Display keys 4
 - functions 12
 - Disposal 43

Index

-
- E**
ECO DECT 30
Emergency numbers
 not possible 7
Enable/disable warning tones 38
Enabling
 answer machine 24
Enabling/disabling advisory tones 38
Enabling/disabling music on hold 38
Enabling/disabling the battery tone 38
End call key 4, 11
Entering characters 45
Environment 42
-
- H**
Handset
 de-registering 33
 display language 36
 locating 33
 registering with assistant 10
 resetting 39
 setting (personalisation) 35
 setting up 9
 switching on/off 11
 transferring a call 16
 use as a baby monitor 29
 using multiple 16, 32
Handsfree
 key 4, 15
 mode 15
 volume 37
Hash key 4
Hearing aids 7
-
- I**
Insert a dialling pause 4
Internal
 consultation 16
 consultation call 17
 making calls 16
Internal call 16
Internal listening in 17
 enable/disable 17
-
- K**
Key (base), registration/paging 5
Key 1 4
Keys
 control key 4, 11
 end call key 4, 11
 handsfree 4, 15
 hash key 4
 key 1 4, 26
 messages 4, 19
 paging key 5
 recall key 4
 star key 4
 talk key 4, 14
-
- L**
Language
 for voice prompting
 (answer machine) 24
 set with assistant 10
Last number redial 14
Liquid 43
List
 answer machine 20
 calls 19
 network mailbox 20
Listening in
 call participant 17
Listening in to a call 17
Listening to a message (network mailbox) 27
Locating
 handset 33
Lock/unlock the keypad 4, 11
-
- M**
Making calls
 accepting a call 15
 internal 16
Manufacturer's advice 42
Medical equipment 7
Menu
 opening 11
 tree 46
Menu navigation 13
Message (answer machine)
 deleting 25
 playback 24
Messages key 4, 19
Messages list 20
Microphone 4
Muting 15
-
- N**
Network mailbox 27
 enable 27
 listening to message 27
Network mailbox list 20
Network provider selection,
 automatic 18
Number
 dialling from the directory 14
 displaying caller's number (CLIP) 17
 entering 14
-
- O**
On/Off key 4
Operating time of handset 44
-
- P**
PABX
 set pause after line seizure 34
 set pause after R key 34

- setting dialling mode 34
 - setting flash time 34
 - Package contents 8
 - Paging 5, 33
 - Pause after line seizure 34
 - Pause after R key 34
 - Phone number
 - select from call list 14
 - select from redial list 14
 - Picking up
 - a call from answer machine 25
 - Pin connections 45
 - Playing back
 - messages (answer machine) 24
 - messages (network mailbox) 27
 - Power adapter 7
 - Power consumption 41
 - Power consumption (base) 44
 - Power consumption (handset) 44
 - Preselection 18
 - Protection from calls, black list 31
-
- Q**
- Quick dial number 14
 - Quick-dial key
 - assign 22
-
- R**
- Radiation-free 30
 - Recall key 4
 - Receiver
 - change volume (during a call) 14, 37
 - change volume (permanently) 37
 - tone quality 37
 - Reception booster, see Repeater
 - Recording an announcement 23
 - Reducing radiation 30
 - Refer to call volume for the ringtone volume
 - Registration/paging key 5
 - Remote operation 26
 - Repeater 33
 - Reset (base) 39
 - Reset (handset) 39
 - Ringtone
 - enable/disable time control 31
 - Ringtone (handset)
 - disable for anonymous calls 31
 - switch on/off from menu 38
 - switch on/off with key 4, 38
 - Room monitoring 29
 - Router connection 8
 - Router, operation with 34
-
- S**
- Safety precautions 7
 - Screensaver 36
 - Searching
 - in the directory 21
 - Sending a directory entry
 - to a handset 22
 - Service 40
 - Set call accept time for answer machine 23
 - Setting flash time (PABX) 34
 - Setting the list type 19
 - Setting the time format 35
 - Setting the wake-up time 28
 - Setting up handset 9
 - Set-up assistant 10
 - Speed dial key 14
 - Speed dialling
 - network mailbox 26
 - Star key 4
 - Status bar 4, 13
 - Switching off
 - handset 11
 - Switching on
 - handset 11
 - Symbol 6
 - answer machine 13, 24
 - battery charge level 13
 - keypad lock 11
 - keys 6
 - procedures 6
 - radio contact 13
 - ringtone 38
 - System PIN
 - changing 39
 - resetting 39
-
- T**
- Talk key 4, 14
 - Technical details 41
 - Telephone jack, pin connections 45
 - Three-party conference 17
 - Time control
 - VIP contact 31
 - Tone quality (receiver) of the handset 37
 - Turning off the wake-up call 28
 - Turning the alarm clock on and off 28
-
- U**
- Upper/lower case and digits 4
-
- V**
- VIP contact 21
 - time control 31
-
- W**
- Warranty 41
-
- X**
- XES mode 34

Issued by

Gigaset Communications GmbH
Frankenstr. 2a, D-46395 Bocholt

© Gigaset Communications GmbH 2019

Subject to availability.

All rights reserved. Rights of modification reserved.

www.gigaset.com