


1.800.497.7479 support@rammount.com rammount.com


Height Adjustment Settings

Loosen the knob on the back of the Level Cup XL to adjust the overall height.



Rubber Cap Placement (Optional)

Follow these steps if your cup/bottle tapers towards the bottom, or if your drink feels somewhat loose in the Level Cup XL. *Important*: Adhesive solution may be extremely watery. Use caution while handling. Use of gloves and paper towels recommended.



RPR-INS-417

Level Cup™ XL


This document, including images, may not be reproduced partly or fully without the expressed written consent of National Products, Inc.



1.800.497.7479 support@rammount.com rammount.com

Height Adjustment Settings

Loosen the knob on the back of the Level Cup XL to adjust the overall height.



Rubber Cap Placement (Optional)

Follow these steps if your cup/bottle tapers towards the bottom, or if your drink feels somewhat loose in the Level Cup XL. *Important*: Adhesive solution may be extremely watery. Use caution while handling. Use of gloves and paper towels recommended.

