



De afwijking van de afmetingen van het verlichtingsset kan niet worden vervangen. Wanneer het snoer beschadigd is, kan het snoer niet worden vervangen. De lampen zijn niet vervangbaar. Deze verlichtingsset heeft 3 functies: 1. "TIMER" voor automatisch 6 uur aan en 18 uur uit, 2. "ON" voor continu aan, 3. "OFF" voor continu uit.

La longueur de la corde de ce luminaire ne peut pas être remplacée, si le cordon est endommagé, il ne peut pas être remplacé. Les ampoules ne peuvent pas être remplacées. Cet ensemble d'éclairage a 3 fonctions pour allumer pendant 6 heures et éteint pendant 18 heures, 2. "ON" pour allumé en continu, 3. "OFF" pour éteint en continu.

Anleitung: Das Kabel dieses Leuchteensatzes kann nicht ausgetauscht werden; wenn das Kabel beschädigt ist, kann das Kabel nicht ausgetauscht werden. Dieses Beleuchtungsset hat 3 Funktionen: 1. "TIMER" = automatische 6 Stunden an und 18 Stunden aus, 2. "ON" = Dauerbetrieb, 3. "OFF" = dauerhaft aus.

Instructions: The external flexible cable or cord of this luminaire cannot be replaced; if the cord is damaged, the cord will be destroyed. The light set has 3 functions: 1. "TIMER" for switching the light automatically (6 hours on and 18 hours off); 2. "ON" for continuously switched on; 3. "OFF" for continuously switched off.



3 x AA (Not included)

Itemnr.: 231512



8 713619 347030

CBD - P.O. BOX 16
1738 ZG - WAARLAND (NL)

CE CE IP44