


## Components



## Parameters

Motor	Operating voltage: 3.7V
Professional Hair Clipper	Centering material: anti-wear brass
Battery	1200 mAh Li-Ion Battery
USB charging	Charging time: about 2 hours
	Operating time with full charge: about 120 minutes
	DC 5V/1A (not include usb adapter)

## Features

REAL POWER  
**99**  
0-99%  
OLD PROTECTIVE LOCK

1. Battery percentage display (00-99)
2. Press three seconds to automatically lock, then press three seconds to open directly.

## How to Charge


The handresser will lock automatically by pressing the switch 3 seconds, and it can be opened directly after pressing the switch 3 seconds. The button below switch is used to adjust speed. High, middle and low speeds are included.

1. Plug the charging cable into the clipper, plug usb into 5V/1A usb adapter (computer/power bank/car charger).
2. The digital LCD dynamically display charging status.
3. Plug the adapter plug into an electrical outlet after confirming that the clipper is power off.

## Fixed Length Function

### 1. Guide Combs Function


The attachment combs of different size work as guide combs which can meet all your requirement of different haircut length (the left and right combs can help you control the trimming orientation and make your hair stylish), also work as guard combs which make haircut safe and easy.



### 3. Fine tune the blade



Moving the button left and right to adjust the blade (0.5mm-2.0mm)



## Blade Removal & Installation

### Blade Removal



• Hold the adjuster, press down the moving blade with the thumb and then remove the blade.



• Please hold with the other hand to avoid the blade falling off.

### Blade Installation



• Adjust the adjustable ring to 2.0 mm before installing the blade



• Direct the blade (B) at the hair clipper's slot (A) and plug in



• Push the blade down until it clicks