


Digital Day Clock

User Manual

Important Note: the buttons on the back of your clock are labeled with symbol only , please use the clearly labeled photo illustration below to identify the appropriate button functions to set your clock.

SET TIME:

Press the **MENU** button to access the set up screen.
Press the **RIGHT/LEFT** button to highlight the field to be modified.
A small blue highlighted square box will appear over the number to be changed.
Use the **UP/DOWN** button to adjust the number
After the modifications are completed, press **OK** button to save.
Press the **MENU** button to go back to the main screen.



SET DATE:

Press the **MENU** button to access the set up screen.
Press the **DOWN** button to highlight the 2nd line.
Press the **RIGHT/LEFT** button to adjust the number
After the modifications are completed, press the **OK** button to save.
Press the **MENU** button to go back to the main screen.

TIME MODE:

Press the **MENU** button to access the set up screen.
Press the **DOWN** button to highlight the 3rd line.
Press the **RIGHT/LEFT** button to switch between:

12 Hour (am/pm)

24 Hour(Military time)

Press the **MENU** button to go back to the main screen.



DATE MODE:

Press the **MENU** button to access the set up screen.
Press the **DOWN** button to highlight the 4th line.
Press the **RIGHT/LEFT** button to switch between:

Month-Day-Year (standard U.S. mode)

Day-Month-Year (standard European mode)

Press the **MENU** button to go back to the main screen.

LANGUAGE: (scroll down; the language option is located below the 4th line)

Press the **MENU** button to access the set up screen.

Press the **DOWN** button to highlight the 5th line.

Press the **RIGHT/LEFT** button to select a language

(choice of: English, French, German, Dutch, Italian, Polish, Spanish...)

Press the **MENU** button to go back to the main screen.

Remote Control: (option)

Note:

To make several modifications to set up screen , after each change simply press **DOWN** button to highlight the next field that you would like to modify and follow the instructions above.

After all the modifications are completed, press the **MENU** button to go back to the main screen.

