

Product image



Insert batteries

1
Open the battery cover and insert "AA" size battery as indicated.




Alarm settings

3
Turn the alarm adjuster anti-clockwise. Slide the alarm ON-OFF switch upwards to turn on.

Timer setting

2
Tune the hour/minute adjuster clockwise until hour/minute hands show actual time.



4
Slide the alarm ON-OFF switch downwards to turn off.

Under the dial of the alarm clock is a button on which you can turn on a light in the dark to read the time. In addition with this button you can also sniff the alarm clock.

Have a good time with West Watches!

www.westwatches.nl



Product afbeelding



Batterij plaatsen

1
Open de batterij cover en plaats een "AA" batterij zoals vermeld.

Tijdinstelling

2
Draai de knop met de klok mee zodat de wijzers van de uren en minuten op de juiste tijd komen te staan.

4
Om het alarm uit te zetten schuif de aan/uit knop naar beneden.

Alarm instelling

3
Draai de alarmknop tegen de klok in. Schuif de aan/uit knop naar boven. Het alarm is ingesteld.

Onder de wijzerplaat van de wekker zit een knop waarmee je een lichtje kunt aandoen om de tijd te lezen in het donker. Daarnaast kan je hiermee ook snoozen.

Have a good time with West Watches!

www.westwatches.nl

