

Netzstecker
diese Anweisungen befördern Sicherheit und Brennzweck
Operating Instructions: The external flexible cable or
luminaire shall be destroyed. The lightbulbs in this rop
the chain must not be used / energised but disposed
connected to another. Do not connect the rope light to
the chain when covered or recessed into a surface. Be
room-temperature after which the ropelight can be ea
bending radius is 4cm. The rope light can be damage
special mounting-clips or tie-raps. During attaching a
proper ventilation during use of this ropelight. Obeyin
ropelight!

