teesa

Travel iron

TSA2012

Návod k obsluze	CS
Bedienungsanleitung	DE
Owner's manual	EN
Εγχειρίδιο χρήσης	GR
Használati utasítás	HU
Instrukcja obsługi	PL
Manual de utilizare	RO
Návod na použitie	SK

teesa

Shot of steam feature does not work	The water tank must be filled up. Fill the iron as described in the section "how to fill the water tank". Steam must be on. Iron should be in the horizontal position. Prime pump briefly. Make short pauses between shots. Be sure you depress the burst of steam button fully.	
Iron is leaking	The steam switch must be set to , until the iron is hot. If the set temperature is too low, the steam will not be produced, and the iron will be leaking.	
	If the shots of steam are used too often, the iron won't be able to reheat, and won't produce steam. Make pauses between shots of steam.	

SPECIFICATION

Main features

- Vertical ironing function
- Dry ironing function
- · Temperature indicator
- Vertical steam shot
- Foldable handle

Technical data

- Steam shot: 50 g
- Continuous steam: 8-18 g/min.
- Steam diffusion: tip
- · Heat up time: around 90 sec.
- Soleplate: ceramic
- · Water tank capacity: 80 ml
- Power cord length: 1,9 m
- Max. power: 1100 W
- Power supply: 110-120 / 220-240 V, 50/60 Hz
- Voltage switch: 115 V / 230 V
- · Set includes: steam iron, refill cup



English Correct Disposal of This Product (Waste Electrical & Electronic Equipment)



(Applicable in the European Union and other European countries with separate collection systems) This marking shown on the product or its literature, indicates that it should not be disposed with other household wastes at the end of its working life. To prevent possible harm to the environment or human health from uncontrolled waste disposal, please separate this from other types of wastes and recycle it responsibly to promote the sustainable reuse of material resources. Household users should contact either the retailer where they purchased this product, or their local government office, for details of where and how they can take this item for environmentally safe recycling. Business users should contact their supplier and check the terms and conditions of the purchase contract. This product should not be mixed with other commercial wastes for disposal.

Made in China for LECHPOL ELECTRONICS Sp. z o.o. Sp.k., ul. Garwolińska 1, 08-400 Miętne.

teesa

www.teesa.pl