

INSTRUCTIONS


- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc) or rechargeable (nickel-cadmium) batteries.
- Do not use rechargeable batteries.
- Non-rechargeable batteries are not to be recharged.
- Only batteries of the same or equivalent type as recommended are to be used.
- Batteries are to be inserted with the correct polarity.
- Exhausted batteries are to be removed from the toy.
- The supply terminals are not to be short-circuited.
- Packing has to be kept since it contains important information.

TO REPLACE BATTERIES

To change the batteries remove the safety screws from the battery compartment cover and make sure the positive (+) and the negative poles are in the correct position as shown in the diagram.

To ensure proper safety and operation, battery replacement must be done by adult. Never let a child use this product unless battery is secured. Batteries are small objects and could be ingested. Keep batteries away from small children. Immediately and safely dispose any used batteries.

Specifications, colors, and contents may vary from illustrations.



NOT SUITABLE FOR CHILDREN
NO CONVIENE A NINOS
NO N ADATTO AI BAMBINI



WARNING:

NOT SUITABLE FOR
CHILDREN UNDER 3 YEARS
DUE TO SMALL PARTS



هسدار ابرلی کم دکان زس ۳ سالی
ملسد فرست : دارای دطعات کم جی لست
تحذیر : غیر ملادم للأطعالی تحت ثلاثة (۳) ات بسبب
القطعة الصغيرة
COUNTRY OF ORIGIN: CHINA
بلد ادمفشاءة : الصين



تست وفقا للمواصفات والمعايير العالمية
Tested according to international standards