

# FN key combination to switch multiple devices

Can connect three devices at the same time (different systems), such as a windows computer, An iphone and an Android tablet.  
Just press the FN key combination to switch smoothly between different devices



## Shortcut key introduction

FN+ESC:	Press 3 seconds to restore settings	FN+U:	Backlight brightness reduced
FN+Left shift	Bluetooth device 1	FN+O:	INS
FN+Left Ctrl:	Bluetooth device 2	FN+X:	mail
FN+LeftAlt:	Bluetooth device 3	FN+TAL:	Backlight mode switching
FN+W:	Direction key switch	FN+right Ctrl:	Backlight monochrome switching
FN+right shift:	Backlight speed increase and decrease	FN+P:	Prtscr
FN+F:	previous piece	FN+[:	Scroll Lock
FN+G:	play / Pause	FN+]:	Pause Break
FN+H:	next track	FN+,:	Home
FN+J:	Volume down	FN+I:	Backlight brightness plus
FN+K:	Mute	FN+':	Page Up
FN+L:	Volume up	FN+,:	stop
FN+C:	my computer	FN+,::	END
FN+M:	Multimedia	FN+/:	Page Down
FN+V:	Browser	FN+1-0:	correspondF1-F12
FN+N:	Favorites	FN+BACKSPACE:	Del
FN+B:	Calculator	FN+\\:	Backlight off
FN+T:	Multi-task control window	FN+Z:	Custom light
FN+E:	Apple display brightness reduced	FN+PN:	Button customization
FN+R:	Apple display brightness plus	FN+Q:	Clear Macro function
FN+Y:	Program list		