

POWER BANK

User Manual

About this user manual

Thank you for purchasing a portable mobile power, which is a compact, lightweight, portable multi-function power system to facilitate you go out or travel, no matter in any environment, immediate charge your portable electronic products (such as: mobile phones, Mp3 / 4, IPOD, Bluetooth, game/ player or so console/ media me models of cameras/camcorders). The note describes how to use this product and important safety issues, please read and retain this manual for future reference.

Important safety precaution

1. Mobile Power is the first time use or long-term storage before use, the mobile power host may have been automatically discharged gradually and fully charged before you use it, please note, it normally takes two or three times the complete charge and discharge cycles, the initial use after in order to achieve optimal performance.
2. Please use the specified charger approved accessories, including adapter charging cable and transmission.
3. Use without power chargers and accessories can be, it may Damage to your portable electronic products and mobile phones the source of the machine.
4. Charge, should be in the position of the ventilation is too high or too low temperature The degree will affect battery performance.
5. Do not put this product on the water. Light or damp rain Cream.
6. Do not drop, strong beat, Vibration or shake the production Products, or it may undermine the internal precision components and intact structure.
7. Please keep this product and related accessories, to avoid home Easy reach of children.

8. Charging, the mobile power hosts a slight fever, which is a normal phenomenon.
9. Do not move power host close to the source of fire or other heat source Heat source in order to avoid danger.
10. Avoid allow metal objects to contact the host of mobile power Charge and discharge the jack, or will cause a short circuit, damage Host.
11. Unauthorized product alteration or repair their own may cause You are unable to use this product and void the warranty.
12. Accordance with local laws, articles of association and limitations, appropriate use of mobile power

host encounter without permission, the need to immediately turn off your cell phone or other electronic products in order to avoid interference.

Product overview

1. Power input
Micro USB for mobile power charging.
2. Power output interface
Type A USB interface output to other devices.

Charging Power station

1. USB-DC3.5 output, line and Micro USB adapter to charge the mobile power available power adapter or computer USB charging for mobile power, the blue indicator shows the mobile power power.
2. If the initial use (or after long-term storage when used), first Mobile power charging activated three times before charging time is approximately 20 hours O'clock, after only 8 hours to charge, power Before they achieve the best results, the process of charging mobile power blue lights.

To charge other devices

With a mobile power supply is used for communication digital products rechargeable DC - 5V input, equipped with a variety of connection fitting, compatible with most mobile phones and digital communication equipment. When connected to an external device, the red indicator light power, the red indicator turns off when the power consumption, Note When you stop mobile power charging to the external device power supply.

