

MAINTENANCE AND REPAIR

The parts of this product that come in contact with food meet the requirements of food-grade certification

1. The glass canister (not the lid) can be placed in the dishwasher or washed by hand.
2. Do NOT use liquids to clean the lid of this storage container. Only use a damp cloth to clean the outside of the lid.
3. This product should be stored in a dry place and avoid direct sunlight.
4. Make sure the product is clean and dry before storage.

PRODUCT PARAMETERS

Rated Wattage: 3W

Rated Voltage: 5V

