

110.00 m m



## Wireless keyboard with device holder

### User Manual

|                     |                          |
|---------------------|--------------------------|
| Dimensions          | 291 x 159 x 16mm         |
| Weight              | 470 grams                |
| Power supply        | 180mAh Li-battery        |
| Operating Frequency | 2.402-2.480GHz           |
| Connection via      | Bluetooth 3.0            |
| Pairing name        | Silvergear Keyboard 1082 |
| Operating range     | Up to 10 meters          |
| Runtime             | Up to 100 hours          |
| Standby time        | 30 days                  |
| Charge time         | 2-3 hours                |
| Compatible          | Android, iOS, Windows    |
| Charging cable type | Micro USB                |

#### 1.Led Display

- Power: The blue indicator lights up 2 seconds when the keyboard is turned on.
- Low power: The blue indicator flashes rapidly when the power is low.

#### 2.System requirements

- iOS all versions.
- Android 3.0 and above.
- Windows Mobile 5.0 and above.
- Bluetooth-enabled PC/Laptop with Windows XP 10 or above.
- Bluetooth-enabled iMac/MacBook with Mac OS X 10.2.8 or above  
(this keyboard may not be totally compatible with all the MacOS devices).

#### 3.Pairing keyboard methods

Pairing with an iPad/iPhone

- Step 1: Slide the power switch to on.  
Step 2: Press "Fn+C". The Bluetooth indicator flashes blue.  
Step 3: Select on the iPad/iPhone: Setting > Bluetooth > On.  
Step 4: The iPad/iPhone displays "Silvergear Keyboard 1082" as an available device.  
Step 5: Select "Silvergear Keyboard 1082".

#### Pairing with Tablets, Smartphones, Laptop and Desktop computers

- Step 1: Slide the power switch to on.  
Step 2: Press "Fn+C". The Bluetooth indicator flashes blue.  
Step 3: Go to the Bluetooth settings menu of your device to activate Bluetooth and search for "Silvergear Keyboard 1082".  
Step 4: The tablet, smartphone, laptop or desktop displays "Silvergear Keyboard 1082" as an available device.  
Step 5: Once the Bluetooth keyboard has successfully been connected to your device, the Bluetooth indicator will turn off

110\*150mm

105克铜版纸双面单色印刷

#### Note:

- Only one device can be actively paired at the same time.
- After pairing for the first time, your device will connect to the keyboard automatically when switching on the keyboard.
- In case of connection failure, delete the pairing record from your device and try the above pairing procedures again.

#### Power saving mode

The keyboard will enter into the power saving mode after not being in use for 15 minutes. To activate the keyboard, press any key and wait 3 seconds.

| Keys | on Android  | on Windows  | on IOS      | Fn + for all w/o |
|------|-------------|-------------|-------------|------------------|
|      | Return      | Return      | Return      | ESC              |
|      | Home        | Browser     | Home        | F1               |
|      | Search      | Search      | Search      | F2               |
|      | Select      | Select      | Select      | F3               |
|      | Copy        | Copy        | Copy        | F4               |
|      | Stick       | Stick       | Stick       | F5               |
|      | Cut         | Cut         | Cut         | F6               |
|      | Pre-Track   | Pre-Track   | Pre-Track   | F7               |
|      | Play/Pause  | Play/Pause  | Play/Pause  | F8               |
|      | Next        | Next        | Next        | F9               |
|      | Volume down | Volume down | Volume down | F10              |
|      | Volume up   | Volume up   | Volume up   | F11              |
|      | Screen Lock | Screen Lock | Screen Lock | F12              |

#### Note:

Press "Fn" and "Q" (Android), "W" (Windows) or "E" (iOS) keys together to switch between Android, Windows or iOS systems after connecting with a corresponding device. Otherwise the keyboard's function key will only be partial valid. For iOS, the Language Exchange function does not work below version 9.2. Press "command+Space" to switch languages.

#### Important guidelines:

- Read the user manual carefully and keep it for reference.
- Use this product only as described in this user manual.
- If the instructions are not followed, the manufacturer may not be held responsible for damage that may result from incorrect use of this product.
- Let repairs be done by a qualified mechanic. Never try to repair the product yourself.
- Do not place heavy objects on the keyboard.
- Keep the product away from water, oil, chemicals and organic liquids.
- Clean the product by lightly rubbing it with a slightly damp cloth.

**GUIDELINES FOR PROTECTION OF THE ENVIRONMENT**  
(WEEE , directive on waste of electrical and electronic equipment)

Your product is designed and manufactured with high quality materials and components which can be recycled and reused. This appliance should not be put into the domestic Garbage at the end of its durability, but must be offered at a central point for the recycling of electric and electronic domestic appliances. This crossed-out wheele bin symbol on the Appliance, instruction manual and packaging puts your attention to this important issue. The materials used in this appliance can be recycling. By recycling used domestic appliances you contribute an important push to the protection of our environment. Ask your local authorities for information regarding the point of recollection.



Overschiestraat 63  
1062 XD Amsterdam  
The Netherlands  
info@silvergear.eu

www.silvergear.eu

art. no.: 1082 batch no.: 19C52

