Pedal Pedal Adapters




KEO compatible

Instructions

- General advice (for adjustable pedals) Before inserting or removing Pedal Plate: reduce the tension of the pedal
- 2. Before cycling with the Pedal Plate: increase the tension

Insert

- 1. Insert Pedal Plate into front of the pedal
- 2. Push back of the Pedal Plate down into the rear clip





Remove (option 1)

- Pull rear clip of the pedal backward
- 2. Remove Pedal Plate from pedal

Remove (option 2)

1. Push against the rear side of the pedal-plate



Remove (high-tension peda

- Insert tool into rear of the Pedal Plate
- 2. Rotate Pedal Plate to release from the pedal





Please note:

The Pedal Plates are designed for normal road use. Visit the FAQ section on www.Pedal-Plate.cc to find the full set of instructions, video's, tips & tricks. If you have any questions please contact us through the form on our website. Enjoy your Pedal Plates!

www.Pedal-Plate.cc

