

# USER MANUAL

## IN THE BOX

- A616d Pro
- MCC

### Table 1: Specifications

COOL WHITE	OPT-5700~6100K	CR170
NEUTRAL WHITE	OPT-4000~5000K	CR170

TURBO	1300lm	120min
HIGH	420lm	135min
MED	150lm	945min
LOW	15lm	53h

MOON	1.1m	114m
Strobe	2.6dB	102m
Beam	IPX7	

Max Output: Sun (Class 3R)  
Max Output: 0.25W (Class I)  
Max Runtime: 6h  
Max Runtime: 53h (CR170)

Max Output: 0.25W (Class I)  
Max Runtime: 17h  
Max Runtime: 53h (CR170)

\* Above data are tested per ANSI/IESA ILM-1-2019 standard in Optiglu tabs for reference.

## Arkfeld Pro

Three Light Sources Portable EDC Flashlight.

### Multi-Language English

(EN) English  
(CN) 简体中文  
(FI) Finnish  
(NO) Norwegian  
(SV) Swedish  
(NL) Nederlands  
(PL) Polska  
(KR) 한국어  
(TH) ไทย  
(FR) Français  
(IT) Italiano  
(SK) Slovenský jazyk  
(PT) Português

### Lock/Unlock

Press the button to turn on or off the UV light.

### Table 1: Specifications

COOL WHITE	OPT-5700~6100K	CR170
NEUTRAL WHITE	OPT-4000~5000K	CR170

Max Output: Sun (Class 3R)  
Max Output: 0.25W (Class I)  
Max Runtime: 6h  
Max Runtime: 53h (CR170)

Max Output: 0.25W (Class I)  
Max Runtime: 17h  
Max Runtime: 53h (CR170)

\* Above data are tested per ANSI/IESA ILM-1-2019 standard in Optiglu tabs for reference.

### Table 1: Specifications

COOL WHITE	OPT-5700~6100K	CR170
NEUTRAL WHITE	OPT-4000~5000K	CR170

Max Output: Sun (Class 3R)  
Max Output: 0.25W (Class I)  
Max Runtime: 6h  
Max Runtime: 53h (CR170)

Max Output: 0.25W (Class I)  
Max Runtime: 17h  
Max Runtime: 53h (CR170)

\* Above data are tested per ANSI/IESA ILM-1-2019 standard in Optiglu tabs for reference.

### Figure 1: Lock/Unlock

Press and hold

### Figure 2: Charging

Battery Level Indicator

GREEN: Charging Completed  
RED: Charging

### Figure 3: Selector--Switch Mode:

UV Light Rotate the selector counterclockwise  
Laser Rotate the selector clockwise

### Figure 4: ON/OFF

Press

OFF ON

### Figure 5: Moonlight

Press and hold

1 to 2 sec

### Figure 6: Turbo

Triple press

### Figure 7: Strobe

Double press

### Figure 8: Change Brightness Level

Press and hold Turbo

Low Medium High

### Figure 9: Timed shutdown

Double press and hold

Blink once: 3 min  
Blink twice: 9 min

### Figure 10: ON/OFF

Press

OFF ON

### Figure 11: Turn on the white light while the laser on

Double press

OFF (white light) ON (High)

### Figure 12: Turn off the white light while the laser on

Double press

ON (white light) OFF

### Figure 13: When the laser and white light are turned on at the same time, change the brightness of the white light

Press and hold

Low High Medium

### Figure 14: ON/OFF

Press

OFF ON

### Figure 15: Battery Level Indicator Display

Four green indicators (>75%)  
Three green indicators (50%-75%)  
Two green indicators (25%-50%)  
One red indicator (<10%)

### Figure 16: Laser

Press and hold

1 to 2 sec

### Figure 17: Moonlight

Press and hold

1 to 2 sec

### Figure 18: Turbo

Triple press

### Figure 19: Strobe

Double press

### Figure 20: Change Brightness Level

Press and hold Turbo

Low Medium High

### Figure 21: Timed shutdown

Double press and hold

Blink once: 3 min  
Blink twice: 9 min

### Figure 22: ON/OFF

Press

OFF ON

### Figure 23: Turn on the white light while the laser on

Double press

OFF (white light) ON (High)

### Figure 24: Turn off the white light while the laser on

Double press

ON (white light) OFF

### Figure 25: When the laser and white light are turned on at the same time, change the brightness of the white light

Press and hold

Low High Medium

### Figure 26: ON/OFF

Press

OFF ON

### Figure 27: Battery Level Indicator Display

Four green indicators (>75%)  
Three green indicators (50%-75%)  
Two green indicators (25%-50%)  
One red indicator (<10%)

### Figure 28: ON/OFF

Press

OFF ON

### Figure 29: Battery Level Indicator Display

Four green indicators (>75%)  
Three green indicators (50%-75%)  
Two green indicators (25%-50%)  
One red indicator (<10%)

### Figure 30: Laser

Press and hold

1 to 2 sec

### Figure 31: Moonlight

Press and hold

1 to 2 sec

### Figure 32: Turbo

Triple press

### Figure 33: Strobe

Double press

### Figure 34: Change Brightness Level

Press and hold Turbo

Low Medium High

### Figure 35: Timed shutdown

Double press and hold

Blink once: 3 min  
Blink twice: 9 min

### Figure 36: ON/OFF

Press

OFF ON

### Figure 37: Turn on the white light while the laser on

Double press

OFF (white light) ON (High)

### Figure 38: Turn off the white light while the laser on

Double press

ON (white light) OFF

### Figure 39: When the laser and white light are turned on at the same time, change the brightness of the white light

Press and hold

Low High Medium

### Figure 40: ON/OFF

Press

OFF ON

### Figure 41: Battery Level Indicator Display

Four green indicators (>75%)  
Three green indicators (50%-75%)  
Two green indicators (25%-50%)  
One red indicator (<10%)

### Figure 42: ON/OFF

Press

OFF ON

### Figure 43: Battery Level Indicator Display

Four green indicators (>75%)  
Three green indicators (50%-75%)  
Two green indicators (25%-50%)  
One red indicator (<10%)

### Figure 44: Laser

Press and hold

1 to 2 sec

### Figure 45: Moonlight

Press and hold

1 to 2 sec

### Figure 46: Turbo

Triple press

### Figure 47: Strobe

Double press

### Figure 48: Change Brightness Level

Press and hold Turbo

Low Medium High

### Figure 49: Timed shutdown

Double press and hold

Blink once: 3 min  
Blink twice: 9 min

### Figure 50: ON/OFF

Press

OFF ON

### Figure 51: Turn on the white light while the laser on

Double press

OFF (white light) ON (High)

### Figure 52: Turn off the white light while the laser on

Double press

ON (white light) OFF

### Figure 53: When the laser and white light are turned on at the same time, change the brightness of the white light

Press and hold

Low High Medium

### Figure 54: ON/OFF

Press

OFF ON

### Figure 55: Battery Level Indicator Display

Four green indicators (>75%)  
Three green indicators (50%-75%)  
Two green indicators (25%-50%)  
One red indicator (<10%)

### Figure 56: ON/OFF

Press

OFF ON

### Figure 57: Battery Level Indicator Display

Four green indicators (>75%)  
Three green indicators (50%-75%)  
Two green indicators (25%-50%)  
One red indicator (<10%)

### Figure 58: Laser

Press and hold

1 to 2 sec

### Figure 59: Moonlight

Press and hold

1 to 2 sec

### Figure 60: Turbo

Triple press

### Figure 61: Strobe

Double press

### Figure 62: Change Brightness Level

Press and hold Turbo

Low Medium High

### Figure 63: Timed shutdown

Double press and hold

Blink once: 3 min  
Blink twice: 9 min

### Figure 64: ON/OFF

Press

OFF ON

### Figure 65: Turn on the white light while the laser on

Double press

OFF (white light) ON (High)

### Figure 66: Turn off the white light while the laser on

Double press

ON (white light) OFF

### Figure 67: When the laser and white light are turned on at the same time, change the brightness of the white light

Press and hold

Low High Medium

### Figure 68: ON/OFF

Press

OFF ON

### Figure 69: Battery Level Indicator Display

Four green indicators (>75%)  
Three green indicators (50%-75%)  
Two green indicators (25%-50%)  
One red indicator (<10%)

### Figure 70: ON/OFF

Press

OFF ON

### Figure 71: Battery Level Indicator Display

Four green indicators (>75%)  
Three green indicators (50%-75%)  
Two green indicators (25%-50%)  
One red indicator (<10%)

### Figure 72: Laser

Press and hold

1 to 2 sec

### Figure 73: Moonlight

Press and hold

1 to 2 sec

### Figure 74: Turbo

Triple press

### Figure 75: Strobe

Double press

### Figure 76: Change Brightness Level

Press and hold Turbo

Low Medium High

### Figure 77: Timed shutdown

Double press and hold

Blink once: 3 min  
Blink twice: 9 min

### Figure 78: ON/OFF

Press

OFF ON

### Figure 79: Turn on the white light while the laser on

Double press

OFF (white light) ON (High)

### Figure 80: Turn off the white light while the laser on

Double press

ON (white light) OFF

### Figure 81: When the laser and white light are turned on at the same time, change the brightness of the white light

Press and hold

Low High Medium

### Figure 82: ON/OFF

Press

OFF ON

### Figure 83: Battery Level Indicator Display

Four green indicators (>75%)  
Three green indicators (50%-75%)  
Two green indicators (25%-50%)  
One red indicator (<10%)

### Figure 84: ON/OFF

Press

OFF ON

### Figure 85: Battery Level Indicator Display

Four green indicators (>75%)  
Three green indicators (50%-75%)  
Two green indicators (25%-50%)  
One red indicator (<10%)

### Figure 86: Laser

Press and hold

1 to 2 sec

### Figure 87: Moonlight

Press and hold

1 to 2 sec

### Figure 88: Turbo

Triple press

### Figure 89: Strobe

Double press

### Figure 90: Change Brightness Level

Press and hold Turbo

Low Medium High

### Figure 91: Timed shutdown

Double press and hold

Blink once: 3 min  
Blink twice: 9 min

### Figure 92: ON/OFF

Press

OFF ON

### Figure 93: Turn on the white light while the laser on

Double press

OFF (white light) ON (High)

### Figure 94: Turn off the white light while the laser on

Double press

ON (white light) OFF

### Figure 95: When the laser and white light are turned on at the same time, change the brightness of the white light

Press and hold

Low High Medium

### Figure 96: ON/OFF

Press

OFF ON

### Figure 97: Battery Level Indicator Display

Four green indicators (>75%)  
Three green indicators (50%-75%)  
Two green indicators (25%-50%)  
One red indicator (<10%)

### Figure 98: ON/OFF

Press

OFF ON

### Figure 99: Battery Level Indicator Display

Four green indicators (>75%)  
Three green indicators (50%-75%)  
Two green indicators (25%-50%)  
One red indicator (<10%)

### Figure 100: Laser

Press and hold

1 to 2 sec

### Figure 101: Moonlight

Press and hold

1 to 2 sec

### Figure 102: Turbo

Triple press

### Figure 103: Strobe

Double press

### Figure 104: Change Brightness Level

Press and hold Turbo

Low Medium High

### Figure 105: Timed shutdown

Double press and hold

Blink once: 3 min  
Blink twice: 9 min

### Figure 106: ON/OFF

Press

OFF ON

### Figure 107: Turn on the white light while the laser on

Double press

OFF (white light) ON (High)

### Figure 108: Turn off the white light while the laser on

Double press

ON (white light) OFF

### Figure 109: When the laser and white light are turned on at the same time, change the brightness of the white light

Press and hold

Low High Medium

### Figure 110: ON/OFF

Press

OFF ON

### Figure 111: Battery Level Indicator Display

Four green indicators (>75%)  
Three green indicators (50%-75%)  
Two green indicators (25%-50%)  
One red indicator (<10%)

### Figure 112: ON/OFF

Press

OFF ON

### Figure 113: Battery Level Indicator Display

Four green indicators (>75%)  
Three green indicators (50%-75%)  
Two green indicators (25%-50%)  
One red indicator (<10%)

### Figure 114: Laser

Press and hold

1 to 2 sec

### Figure 115: Moonlight

Press and hold

1 to 2 sec

### Figure 116: Turbo

Triple press

### Figure 117: Strobe

Double press

### Figure 118: Change Brightness Level

Press and hold Turbo

Low Medium High

### Figure 119: Timed shutdown

Double press and hold

Blink once: 3 min  
Blink twice: 9 min

### Figure 120: ON/OFF

Press

OFF ON

### Figure 121: Turn on the white light while the laser on

Double press

OFF (white light) ON (High)

### Figure 122: Turn off the white light while the laser on

Double press

ON (white light) OFF

### Figure 123: When the laser and white light are turned on at the same time, change the brightness of the white light

Press and hold

Low High Medium

### Figure 124: ON/OFF

Press

OFF ON

### Figure 125: Battery Level Indicator Display

Four green indicators (>75%)  
Three green indicators (50%-75%)  
Two green indicators (25%-50%)  
One red indicator (<10%)

### Figure 126: ON/OFF

Press

OFF ON

### Figure 127: Battery Level Indicator Display

Four green indicators (>75%)  
Three green indicators (50%-75%)  
Two green indicators (25%-50%)  
One red indicator (<10%)

## CONTENTS

(EN) English ..... 01  
(CN) 简体中文 ..... 02  
(FI) Finnish ..... 03  
(NO) Norwegian ..... 04  
(SV) Swedish ..... 05  
(NL) Nederlands ..... 06  
(PL) Polska ..... 07  
(KR) 한국어 ..... 18  
(TH) ไทย ..... 20  
(FR) Français ..... 21  
(IT) Italiano ..... 23  
(SK) Slovenský jazyk ..... 24  
(PT) Português ..... 25

### Table 1: Specifications

COOL WHITE	OPT-5700~6100K	CR170
NEUTRAL WHITE	OPT-4000~5000K	CR170

Max Output: Sun (Class 3R)  
Max Output: 0.25W (Class I)  
Max Runtime: 6h  
Max Runtime: 53h (CR170)

Max Output: 0.25W (Class I)  
Max Runtime: 17h  
Max Runtime: 53h (CR170)

\* Above data are tested per ANSI/IESA ILM-1-2019 standard in Optiglu tabs for reference.

### Figure 1: Lock/Unlock

Press and hold

### Figure 2: Charging

Battery Level Indicator

GREEN: Charging Completed  
RED: Charging

### Figure 3: Selector--Switch Mode:

UV Light Rotate the selector counterclockwise  
Laser Rotate the selector clockwise

### Figure 4: ON/OFF

Press

OFF ON

### Figure 5: Moonlight

Press and hold

1 to 2 sec

### Figure 6: Turbo

Triple press

### Figure 7: Strobe

Double press

### Figure 8: Change Brightness Level

Press and hold Turbo

Low Medium High

### Figure 9: Timed shutdown

Double press and hold

Blink once: 3 min  
Blink twice: 9 min

### Figure 10: ON/OFF

Press

OFF ON

### Figure 11: Turn on the white light while the laser on

Double press

OFF (white light) ON (High)

### Figure 12: Turn off the white light while the laser on

Double press

ON (white light) OFF

### Figure 13: When the laser and white light are turned on at the same time, change the brightness of the white light

Press and hold

Low High Medium

### Figure 14: ON/OFF

Press

OFF ON

### Figure 15: Battery Level Indicator Display

Four green indicators (>75%)  
Three green indicators (50%-75%)  
Two green indicators (25%-50%)  
One red indicator (<10%)

### Figure 16: Laser

Press and hold

1 to 2 sec

### Figure 17: Moonlight

Press and hold

1 to 2 sec

### Figure 18: Turbo

Triple press

### Figure 19: Strobe

Double press

### Figure 20: Change Brightness Level

Press and hold Turbo

Low Medium High

### Figure 21: Timed shutdown

Double press and hold

Blink once: 3 min  
Blink twice: 9 min

### Figure 22: ON/OFF

Press

OFF ON

### Figure 23: Turn on the white light while the laser on

Double press

OFF (white light) ON (High)

### Figure 24: Turn off the white light while the laser on

Double press

ON (white light) OFF

### Figure 25: When the laser and white light are turned on at the same time, change the brightness of the white light

Press and hold

Low High Medium

### Figure 26: ON/OFF

Press

OFF ON

### Figure 27: Battery Level Indicator Display

Four green indicators (>75%)  
Three green indicators (50%-75%)  
Two green indicators (25%-50%)  
One red indicator (<10%)

### Figure 28: ON/OFF

Press

OFF ON

### Figure 29: Battery Level Indicator Display

Four green indicators (>75%)  
Three green indicators (50%-75%)  
Two green indicators (25%-50%)  
One red indicator (<10%)

### Figure 30: Laser

Press and hold

1 to 2 sec

### Figure 31: Moonlight

Press and hold

1 to 2 sec

### Figure 32: Turbo

Triple press

### Figure 33: Strobe

Double press

### Figure 34: Change Brightness Level