


THUNDERZ



Manual

Wireless earbuds pro TZ-66

Introduction



1. Touch control button
2. LED indicator earbud
3. Ear tip
4. Wingtip
5. Charging contact points
6. Type-C charging port
7. Wireless charging base
8. Charging case
9. Charging station earbud
10. LED indicator charging case

Connecting earbuds

Steps


1. Turn on Bluetooth on your device.
2. Pick up the earbuds from the charging case. The earbuds turn on, start pairing and search automatically for Bluetooth connection.
3. Connect the earbuds to your device via «ThunderZ TZ-66» in the Bluetooth settings.

Note

When using the earbuds for the first time, remove the blue label from the bottom side of the earbuds.

Automatic connection:
After the earbuds are successfully connected to your device the first time:
"Pick up the earbuds = automatic connection"
"Put earbuds in charging case = earbuds disconnect"

Touch control



| Function | Control |
|----------------------------|--|
| Play/ Pause | 1 x Touch L/R |
| Next/ Previous song | 2 x Touch for next song L 2 x Touch for previous song R |
| Volume + / Volume - | 3 seconds hold press volume +, L 3 seconds hold press volume -, R |
| Answer/ Hang up call | 1 x Touch L/R |
| Reject call | 2 seconds hold press L/R |
| Voice assistant activation | 3 x Touch L/R |
| Turn on earbud | 3 seconds hold press L/R |
| Turn off earbud | 5 seconds hold press L/R |

Tip:
Either earbud can be used individually. When doing so, the functions Volume +/- and Next/ Previous song will be disabled.

LED indicator

Charging case

| Status | LED |
|---|----------------------------------|
| Charging via Type-C cable | Red light flashes |
| Fully charged via Type-C cable | Red light on |
| The earbuds charge in the charging case | Blue light on (3 sec.), then off |
| Low battery | Red light flashes |

Earbud

| Status | LED |
|-------------------|---|
| Charging | Red light on |
| Fully charged | Blue light on (5 seconds), then off |
| Low battery | Red light flashes |
| Search connection | Red and blue light flashing alternately |
| Connected | No light |
| Music/ calling | No light |
| Turn on | Red and blue light flashing for 2 seconds |
| Turn off | Red light flashes for 2 seconds |

Specifications

| | |
|--------------------------------|---------------------------------|
| Bluetooth version | V5.0 + EDR |
| Bluetooth range | 10 meters/ 33 ft (unobstructed) |
| Dimensions earbud | 25.2 x 23.3 x 21.9 mm |
| Dimensions charging case | 71.1 x 40.0 x 27.2 mm |
| Weight earbud | 4.5 gram/ 0.16 oz |
| Charging time earbuds | 1 hr |
| Charging time charging case | 1 hr (via Type-C) |
| Standby time | 60 hrs |
| Battery capacity earbud | 40 mAh |
| Battery capacity charging case | 250 mAh |
| Input wireless charging base | DC 5V/ 1A |

Package contents

- 1 x Wireless earbud pro L/R
- 1 x Charging case
- 2 x Ear tips (S/M/L), 2 x Wingtip (S/M), 1 x Casual tip
- 1 x Type-C Charging cable
- 1 x Manual

Reset

When one or both earbuds will not connect to your device, reset the earbuds.

Steps

1. Remove «ThunderZ TZ-66» from all Bluetooth devices it has been connected to, and turn off the Bluetooth on your device.
2. Turn off both earbuds and put them in the charging case.
3. Pick up the earbuds from the charging case and turn on the earbuds. Turn on Bluetooth on your device and connect «ThunderZ TZ-66» to your device in the Bluetooth settings.
4. The Bluetooth connection of the earbuds has now been reset.

Note


Always reset the 2 earbuds at the same time.

Warnings



1. The earbuds cannot be submerged in water and do not withstand when used during shower or swimming.
2. Do not place the earbuds in direct sunlight or in hot/ moisture places.
3. Turn off the earbuds when not being used.
4. Do not try to disassemble the product.
5. Do not drop the earbuds or knock the earbuds to other surfaces.
6. If the volume of the earbuds is too long on high volume, it may lead to health problems. Be aware.

How to wear



1. Choose and place the ear tip that best suit your ears.
2. Insert the earbud in the inner ear.
3. Turn the wingtip and find the most comfortable position.




THUNDERZ



Gebruiksaanwijzing

Wireless earbuds pro TZ-66

Introductie



1. Touch control button
2. LED indicator earbud
3. Ear tip
4. Wingtip
5. Oplaadcontactpunten
6. Type-C oplaadpunt
7. Draadloze oplaadbasis
8. Oplaadcase
9. Oplaadstation earbud
10. LED indicator oplaadcase

Verbinding maken

Stappen


1. Zet Bluetooth aan op je apparaat.
2. Pak de earbuds uit de oplaadcase. De earbuds activeren, pairen en zoeken automatisch naar een Bluetooth verbinding.
3. Verbindt de earbuds met je apparaat via «ThunderZ TZ-66» in de Bluetooth instellingen.

Note

Wanneer je de earbuds voor de eerste keer gebruikt, zorg dan dat je het blauwe stikkertje onderaan de earbuds verwijderd.

Automatisch verbinding maken:
Nadat je de earbuds de eerste keer met je apparaat hebt verbonden:
"Earbuds uit de oplaadcase = automatisch verbonden"
"Earbuds terug in de oplaadcase = verbinding verbreken"

Touch bediening



| Functie | Bediening |
|---------------------------|--|
| Play/ Pauze | 1 x Tippen L/R |
| Volgend/ Vorig nummer | 2 x Tippen volgend nummer L 2 x Tippen vorig nummer R |
| Volume + / Volume - | 3 seconden ingedrukt houden volume +, L 3 seconden ingedrukt houden volume -, R |
| Oproep opnemen/ eindigen | 1 x Tippen L/ R |
| Oproep weigeren | 2 seconden ingedrukt houden L/R |
| Voice assistent activeren | 3 x Tippen L/R |
| Aanzetten | 3 seconden ingedrukt houden L/R |
| Uitzetten | 5 seconden ingedrukt houden L/R |

Tip:
Je kunt de earbuds ook afzonderlijk gebruiken. Hiermee vervallen wel de controls Volume +/- en Volgend/ vorig nummer.

LED indicator

Oplaadcase

| Status | LED |
|--|--------------------------------------|
| Opladen via de Type-C kabel | Rood licht knippert |
| Volledig opgeladen via de Type-C kabel | Rood licht aan |
| De earbuds laden op in de oplaadcase | Blauw licht aan (3 sec.), daarna uit |
| Lage batterij | Rood licht knippert |

Earbud

| Status | LED |
|--------------------|--|
| Opladen | Rood licht aan |
| Volledig opgeladen | Blauw licht aan (5 seconden), daarna uit |
| Lage batterij | Rood licht knippert |
| Verbinding maken | Rood en blauw licht knippert |
| Verbonden | Geen licht |
| Muziek/ bellen | Geen licht |
| Aanzetten | Rood en blauw licht knippert 2 seconden |
| Uitzetten | Rood licht knippert 2 seconden |

Specificaties

| | |
|--------------------------------|-----------------------------|
| Bluetooth versie | V5.0 + EDR |
| Bluetooth bereik | 10 meter (zonder obstakels) |
| Afmetingen earbud | 25,2 x 23,3 x 21,9 mm |
| Afmetingen oplaadcase | 71,1 x 40,0 x 27,2 mm |
| Gewicht earbud | 4,5 gram |
| Oplaadtijd earbud | 1 uur |
| Oplaadtijd oplaadcase | 1 uur (via Type-C) |
| Standbytijd | 60 uur |
| Batterij capaciteit earbud | 40 mAh |
| Batterij capaciteit oplaadcase | 250 mAh |
| Input draadloze oplaadbasis | DC 5V/ 1A |

Verpakkingsinhoud

- 1 x Wireless earbud pro L/R
- 1 x Oplaadcase
- 2 x Ear tips (S/M/L), 2 x Wingtip (S/M), 1 x Casual tip
- 1 x Type-C Oplaadkabel
- 1 x Gebruiksaanwijzing

Reset

Wanneer een of beiden earbuds niet wilt connecten met je apparaat, reset dan beiden earbuds.

Stappen

1. Verwijder «ThunderZ TZ-66» van je apparaat in de Bluetooth instellingen, en zet Bluetooth uit.
2. Zet beiden earbuds uit en stop deze in de oplaadcase.
3. Pak de earbuds uit de oplaadcase en zet de earbuds aan. Zet de Bluetooth op je apparaat aan en verbindt «ThunderZ TZ-66» aan je apparaat via de Bluetooth instellingen.
4. De Bluetooth verbinding van de earbuds is nu gereset.

Note


Reset altijd de 2 earbuds tegelijkertijd.

Waarschuwingen



1. De earbuds kunnen niet ondergedompeld worden in water en je kunt niet douchen of zwemmen met deze earbuds.
2. Plaats de earbuds nooit in direct zonlicht of op warme/vochtige plekken.
3. Zet de earbuds uit wanneer je deze niet gebruikt.
4. Probeer het product niet te demonteren.
5. Laat de earbuds niet vallen of stoot deze niet tegen andere oppervlakken.
6. Wanneer het volume van de earbuds te lang op een te hoog volume staat, kan dat leiden tot gezondheidsklachten. Ben ervan bewust.

Earbuds plaatsen



1. Kies en bevestig de eartip die het best bij je oor past.
2. Bring de earbud in de binnenkant van je oor.
3. Draai de wingtip in je oorschelp en vind de meest comfortabele positie.

