



## Operation instructions



## The features of product

1. The appearance design is beautiful and convenient to carry and go out.
2. Changeable universal polisher, which can meet different demands for the manicure.
3. The adjustable positive and negative rotation, 3 gears speed adjustment, LCD gears indicator.
4. Double TYPE-C interface design for chassis and fuselage, convenient and convenient.
5. Adopt a high-performance lithium battery, and USB charging indicator.
6. The function of battery status query.

## Product usage

1. The polisher is better to operate:  
It is more fast to switch the polisher by pulling out and plugging in it directly.
2. Start up operation  
Press the power key "⏻" for 2 seconds, the machine will start to polish at 1 gear positive rotation, and the L icon light will be on.
3. Gear switch:  
Press the power key "⏻" shortly to switch L-M-H gears, and the corresponding gear icon will be on.
4. Positive and negative rotation operation:  
Press the positive and negative key "↻" to switch the positive rotation and negative rotation, and when the corresponding gears icon is on, the machine is at positive rotation, and when the icon is flickering, the machine is at negative rotation;
5. Shut down operation:  
In the condition of operation, press the power key "⏻" for 2 seconds to shut down;
6. Shutdown condition  
Power off: Short press the "⏻" button, "H" and LMH icon light > 70% power, "H" and L M icon light > 40% power, "H" and L icon light < 30% power;
7. Charging indication:  
Plug in the USB cable, "H" LED flash, Charging status, If the "H" long bright, for the battery is full;
8. When the machine is idle without polishing for 10 minutes, it will shut down automatically.

## Product parameter

Product name	Nail Instrument	Product model	M3
Charging voltage	DC5V	Working voltage	DC3.7V
Max power	<0.5W	Rotation speed	15000.RPM
Battery capacity	500mAh	Charging time	2H
Operating time	About 2H	Suitable polisher	2.35mm
The net weight of product	82g	The dimension of product	130*23*23mm
		Base dimension	60*37*30mm

## Notes

1. Please use DC5V adapter to charge;
2. Please don't clean the machine by alcohol/detergent/the liquid containing mercury/alkali/acidoid;
3. The product isn't water-proof, please don't clean it by water.
4. The product isn't a toy for children, please store it at a place where is far from the children.

## Warranty card

Thank you to purchase the product of our company, and please keep the after-sale warranty card well for your deserved rights and interests

Name: \_\_\_\_\_ Tel: \_\_\_\_\_  
 Product name: \_\_\_\_\_ Product model: \_\_\_\_\_  
 Purchasing date: \_\_\_\_\_  
 Address: \_\_\_\_\_

- The following situations are not in the warranty coverage, careless or mistaken operation and other man-made damage.
- The warranty card loss or damage are not in the warranty coverage.
- The damages due to the natural disaster and other force majeure aren't in the warranty coverage.
- Other consumable items are not in the warranty coverage.
- Since the purchasing date, and the machine is operated normally, if the main engine is broken, it will be guaranteed for one year.



# Nail Instrument

## Operation instructions

