FRONT

Skullcandy

USER GUIDE

Cassette

Pairing Mode
"Off Mode"

00:05

Pair New Device
"Cassette"

Power - On

00:01

Power - Off

00:04

Play/Pause

1x

Volume Up

1x

Volume Down

1x

Track Forward

00:02

Track Back

00:02

Answer/End

1x

Activate Assistant

2x

Charge

| | | |