Gebruiksaanwijzing – Frummel Buitenbeestjes

Veilig speelplezier voor kinderen vanaf 6 maanden

Wat zit er in de verpakking?

- 3 fidget spinners met zuignap:
  - Vlinder Vievé
  - Slakje Sjoerd
  - Bijtje Bas

Gebruiksaanwijzing

1. Kies een glad, schoon oppervlak (zoals een badrand, raam, tegel of tafel).
2. Druk de zuignap stevig aan om te hechten.
3. Laat draaien en speel.

Tips voor gebruik

- Gebruik in bad, onderweg of thuis.
- Laat je kind zelfstandig ontdekken en draaien.
- Maak samen verhaaltjes met de drie figuren.

Reiniging en onderhoud

- Reinig met een vochtige doek en milde zeep.
- Spoel de zuignap af onder de kraan indien nodig.
- Laat volledig drogen voor hergebruik.

Niet onderdompelen of gebruiken onder stromend water.

Veiligheidsvoorschriften

- CE-gemarkeerd speelgoed., geschikt voor kinderen vanaf 6 maanden.
- Alleen gebruiken onder direct toezicht van een volwassene.
- Controleer het speelgoed regelmatig op slijtage of beschadigingen.
- Niet gebruiken indien onderdelen losraken of beschadigd zijn.
- Buiten bereik van dieren houden.
- Niet geschikt voor consumptie.

- Verpakking is geen speelgoed. Verwijder alle verpakkingsmaterialen vóór gebruik.

Contact

Vragen of opmerkingen? Bezoek www.mijnfrummel.nl en we helpen je graag!

Instructions – Frummel Garden Friends

Safe and cheerful playtime fun for babies and toddlers

What's in the box?

- 3 suction cup fidget spinners:
  - Bella the Butterfly
  - Scoot the Snail
  - Buzzy Ben

Instructions for use

1. Choose a smooth, clean surface (such as a bathtub edge, window, tile or table).
2. Press the suction cup firmly to attach.
3. Spin and play.

Tips for play

- Use during bath time, on the go or at home.
- Let your child explore and spin independently.
- Create fun stories around the three characters.

Cleaning and maintenance

- Clean with a damp cloth and mild soap.
- Rinse suction cup under the tap if needed.
- Let dry completely before reuse.

Do not submerge or use under running water.

Safety warnings

- CE certified toy, suitable for children from 3 months.
- Use only under direct adult supervision.
- Check regularly for wear or damage.
- Do not use if any parts become loose or broken.
- Keep out of reach of pets.
- Not suitable for consumption.
- Packaging is not a toy. Remove all packaging materials before use.

Contact

Questions or comments? Visit www.mijnfrummel.nl – we're happy to help!