PLEASE READ THE MANUAL CAREFULLY BEFORE USE.

KEEP THIS MANUAL FOR FUTURE REFERENCE

CONTENTS:

x 1 Luxe Lie-on Float

HOW TO USE:

1. Inflate chambers by pinching each valve with fingers and inserting the nozzle of your Sunnylife Electric Air Pump, Car Air Pump or Hand Pump into valve opening. Be sure inflatables are at room temperature before it is inflated, otherwise you may risk temperature shock which can cause it to damage.

2. Do not over inflate. Do not attempt to remove every wrinkle from your inflatable. This will increase its risk of bursting or obtaining a puncture when in use.

3. Some inflatables have multiple valves. Always inflate starting from valve 1 working your way up so as to finish on the highest number. (ie. Valve 1, valve 2, valve 3 etc.)

4. In case of small punctures, use the included repair patch by following the instructions on the back.

5. Where there are multiple sections to your inflatable, unfold it fully before inflating. Inflate slowly, allowing air to seep into smaller sections.

6. After inflating, cover valve opening with finger. Then quickly insert plug fully into valve opening until head of plug touches the valve opening.

7. Press closed valve into the inflatable so that it is flat with the surface.



HOW TO MAINTAIN:

- Do not drag your inflatable over sharp objects or on rough surfaces.
- Avoid contact with hot or sharp surfaces.
- The air in your inflatable will shrink or expand if left out in the weather. When your inflatable is not in use, it is best kept somewhere out of the elements.
- To clean, rinse in fresh water and air dry.

In order to use safely, please reference the warnings. Only use pool float as instructed. Do not exceed the indicated number of users.

PRODUCT SPECS:

Material: Non-toxic PVC

WARNING:

WARNING:

WARNING:

WARNING:

WARNING: