FR - Pour usage intérieur uniquement. Le cordon de cet ensemble d'éclairage ne peut pas être remplacé ; si le cordon est endommagé, l'ensemble d'éclairage doit être détruit. Les lampes ne peuvent pas être remplacées. Cette guirlande n'est pas un jouet. Veuillez hors de portée des enfants. Cet ensemble d'éclairage a 3 fonctions : 1. "ON" pour allumé en continu, allumé pendant 6 heures et éteint pendant 18 heures, 2. "ON" pour allumé en continu, 3. "OFF" pour éteint en continu.

DE - Nur für den Einsatz im Innenbereich. Das flexible Kabel dieses Beleuchtungssets kann nicht ausgetauscht werden, wenn das Kabel beschädigt ist, ist das Beleuchtungsset zu beseitigen. Die Lampen können nicht ausgetauscht werden. Diese Lichtkette ist kein Kinderspielzeug - Bitte für Kinder unzugänglich anbringen. Dieses Beleuchtungsset hat 3 Einstellungen: 1. „ON" = Dauerbetrieb, 2. „TIMER" = automatisch 6 St. an und 18 St. aus, 3. „OFF" = dauerhaft aus.

EN - The external flexible cable or cord of this luminaire cannot be replaced, if the cord is damaged, the luminaire shall be destroyed. Do not connect the chain to the supply while it is in the packing. The lamps are not replaceable. This light set has 3 functions: 1. "ON" for continuously switched on, 2. "TIMER" for switching the light on/off automatically (6 hours on and 18 hours off), 3. "OFF" for continuously switched off.

3 x AA (Not included)

Itemnr.: 231132

8 713619 395741

CBD P.O.BOX 16
1738 ZG WAARLAND (NL)