FR Ce œuf vibrant sans fil dispose de 10 modes de vibration différents, très excitants, tous ajustables à l´aide de la télécommande sans fil. D´un mode confortable et doux à un mode de vibration extrêmement fort, vous le commandez avec votre télécommande jusqu´à une distance de 20 mètres. L´œuf est recouvert d´une couche douce et agréable au toucher. Ce qui lui donne un look et un design uniques. La télécommande est en acier inoxydable brossé et est équipée d´un fermoir, ce qui vous permet de l´attacher facilement à votre porte-clés. Les piles pour l´œuf ainsi que pour la télécommande sont fournies gratuitement dans le coffret. Conseil : donnez la télécommande à votre partenaire, il ou elle prendra le contrôle de l´œuf.

Rotations per minute:	12000 RPM
Speed modes:	10
Wireless remote:	Yes
Noise level:	Max. 75 dB
Sizes:	ø 34 mm - ↕ 50 mm
Batteries:	Incl. - 6x AG13
Material:	ABS
Waterproof:	Yes
Phthalate free:	Yes

SHOTS TOYS

Shots Toys © is a registered trademark of Shots BV,
Veesteeg 12, 6658 KP, Beneden-Leeuwen - NL (EU)
Tel: +31 (0) 487 519 333 - info@shots.nl - www.shots.nl

Shots America LLC, 26420 Summit Circle, Santa Clarita,
California 91350 - USA - Tel: +1 (661) 222-7855,
info@shotsamerica.com - www.shotsamerica.com

Designed in Holland - Assembled in China

This Shots product is protected as a registered design.
Claim your warranty at: register.shots.nl

follow us: /shotsmedia and /shotsamerica

follow us: /shotsmedia and /shots_america

follow us: /shotsnl