



# **USER MANUAL**

## **DIGITAL SCALE**

*Thank you for choosing the KRUMBLER Digital Scale.  
Let's get ready to Krumble.*

### **FEATURES**

- Weigh in G, OZ, CT, TL, DWT, OZT and GN
- Division: 0.01g
- TARE and counting functionality
- Display: backlit LCD
- Dimensions: 116 x 64 x 17mm
- Weight: 110g
- Powered by 2 AAA batteries
- Auto power off after 1 minute without operation

### **WEIGHING**

1. Place the scale on a flat surface and press ON/OFF key to turn on the scale. Wait until 0,0 is displayed.
2. Place the object in the center of the weighing platform.
3. Use the UNITS key to select the desired measurement unit.
4. Press TARE to reset the weight to 0.

### **CALIBRATION**

1. Place the scale on a flat surface and press ON/OFF key to turn on the scale. Wait until 0,0 is displayed.
2. Press the UNITS key for 3 seconds. The screen will display "CAL". Press the UNITS key again to verify that you wish to calibrate the scale.
3. The required calibration weight will now be displayed. Place the required weight on the scale.
4. If successful, the scale display will show PASS.
5. Press ON/OFF to turn off the scale, the calibration is now finished.

## COUNTING

1. Place the scale on a flat surface and press ON/OFF key to turn on the scale. Wait until 0,0 is displayed.
2. Place a sample amount (25, 50, 75 or 100) of the objects you wish to count on the platform.
3. Press and hold the PCS key for 2 seconds until the number 25, 50, 75 or 100 is displayed.
4. Press the UNITS key to select the correct number of your sample amount.
5. Press PCS to confirm the sample amount. PCS will now light up on the display to show that the scale is in counting mode.
6. Remove the samples from platform.
7. Place any amount of objects you wish to count on the scale.
8. Switch between weighing mode and counting mode by pressing UNITS or PCS key respectively.

## REMINDER

1. Do not overload the scale to avoid damage to the loadcells.
2. Avoid exposure to extreme heat or cold. Normal room temperature (10 to 30 degrees Celcius) is advised.
3. Place the objects you want to weigh in the center of weighing platform.
4. Remove the batteries when the scale will not be used for a long time.
5. Keep the scale in a clean environment, do not immerse the scale in water or use chemical/abrasive cleaning products.
6. Handle with care.
7. Cook and bake with love!

