

LUMINAIRES

Stelin



TOUCH BUTTON OPERATION

Touch once to turn the lamp ON or OFF.

Dimming

While the lamp is on, touch continiously to increase brightness. Touch continiously again to decrease brightness.

Changing color temperature

While lamp is OFF, touch for +/- 6 seconds. The lamp turns on. You can now cycle between 3 color temperatures by touch: 2700K - warm white 4000K - neutral white

5000K - cool white

Once a temperature is choosen, wait for the lamp to turn off automatically. The color temperature is now set.

When turning the lamp on, it will be turned on in the new color temperature set.