



XTRAZZ
SILICONE CLAY EARPLUGS

XTRAZZ
SILICONE CLAY
EARPLUGS



6 PAIR
Pack of 12 capsules
Weight : 1.7 g/PCS

SNR 27dB

MINIMUM SOUND ATTENUATION

Frequency [Hz]	125	250	500	1000	2000	4000	8000
Sound attenuation [dB]	27.5	34.4	24.3	27.0	36.0	42.6	39.2
Standard deviation [dB]	5.4	3.8	4.3	4.4	4.0	3.7	4.7
APV [dB]	22.0	20.6	20.0	22.6	32.0	38.9	34.4



EN 352-2:2002 (EU) 2019/225
CE 2834



HOW TO USE
(Please read before use)

Recommendation
Wear should ensure that the plugs are firm, adjusted and maintained in contact with the eardrum's membrane. The earplugs are worn at all times in noisy surroundings. The earplugs may be adjusted slightly by stretching the earlobes.

Cleaning
The earplugs are reusable and should be handled regularly for cleaning with neutral liquid soap and lukewarm water to clean and disinfect. Earplugs should be discarded if a no longer used. Dry earplugs before inserting them in the ear. Use washing between 0°C and 37°C. Never use the earplugs beyond 37°C. Stop wearing the earplugs if there are signs of allergic reaction or if you experience any discomfort. For more information on our products, our earplugs are available at www.xtrazz.com.

XTRAZZ
SILICONE CLAY EARPLUGS

8x6x1.7cm