

## SAVE THESE IMPORTANT SAFETY INSTRUCTIONS

Please read all instructions before using this appliance.

These instructions are also available on our website. Please visit

[www.hot-europe.com](http://www.hot-europe.com)

**WARNING:** The appliance has a heated surface. Persons insensitive to heat must be careful when using the appliance.

**WARNING:** If water leaks from the appliance, the appliance should no longer be used.

This appliance can be used by children aged from 8 years and above, and by persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.

Children shall not play with the appliance.

Cleaning and user maintenance shall not be made by children without supervision.

If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.

**WARNING:** Should this product malfunction, do not attempt to repair it.

This appliance has no user serviceable parts or components.

**WARNING:** This appliance must not be taken into the bathroom.

**WARNING:** Do not operate under a blanket or pillow as excessive heating can occur causing fire, electric shock or injury to persons.

**WARNING:** Only use this appliance for its intended purpose as described in this manual. Do not use attachments not recommended by the manufacturer.

**WARNING:** DO NOT use on:

- Any area of the body that is swollen, burned or inflamed or when skin erupts or ulcerated sores are present.
- Any area of the body that is anaesthetized or lacks the ability to sense pressure or pain unless approved by your doctor.
- Legs with varicose veins.
- Calves of legs with unexplained pain.
- Areas of the skin with severe acne, a rash or other skin ailments.

**NOTE:** The Pediprep Spa should not be used with any additives which could bubble, or salts which could corrode key parts and components.

**NOTE:** Consult your doctor before use if you are pregnant. Do not use if you suffer from Diabetes or any other circulatory disease or illness. Massage should be pleasant and comfortable. Should pain or discomfort result, discontinue use and consult your doctor.

**NOTE:** This appliance contains water which could splash during use, please ensure that the appliance is operated on a water resistant surface to prevent damage to flooring etc.

**IMPORTANT:** DO NOT allow the footbath to run continuously for longer than 20 minutes. Switch it off and allow the appliance to cool down to room temperature.

This product carries the CE mark and is manufactured in conformity with the Electromagnetic Directive 2014/30/EU, the Low Voltage Directive 2014/35/EU, the ROHS Directive 2011/65/EU and the Energy and using Products Directive 2009/125/EC.

## GUARANTEE AND SERVICE SECTION:

Your Revlon appliance is guaranteed against defects under normal use for two years from the original date of purchase. If your product does not perform satisfactorily because of defects in materials or manufacture, within the warranty period, it will be replaced. Please retain your receipt or other proof of purchase for all claims within the warranty period. The guarantee becomes void if the proof of purchase is not presented. For all claims within the warranty period please contact our Support Team. This guarantee does not cover defects which have occurred due to misuse, abuse, or are caused by failure to follow the instructions contained within this manual. This does not affect your consumer statutory rights. The manufacturing date is given by the 4 digit Batch Number marked on the rear of the product. The first 2 digits represent the week of manufacture, and the last 2 digits represent the year of manufacture. Example: 3416 - product manufactured week 34 of the year 2016.

For product support, please visit us at:


[www.hot-europe.com/support](http://www.hot-europe.com/support)

Or contact us by phone:

**+44 (0) 115 965 7430**

For product information, visit us at:

[www.revlonbeautycare.com](http://www.revlonbeautycare.com)

 This appliance complies with EU legislation 2012/19/EU on end of life recycling. Products showing the 'Crossed Through' wheeled bin symbol on either the rating label, gift box or instructions must be recycled separately from household waste at the end of their useful life.

Please DO NOT dispose of appliance in normal household waste.

Your local appliance retailer may operate a 'take-back' scheme when you are ready to purchase a replacement product, alternatively contact your local government authority for further help and advice on where to take your appliance for recycling.

220-240V ~ 50-60Hz 50W

The REVLON® trademark is used under license from Revlon, by Helen of Troy Limited.

Made in China.

European Headquarters

Kaz Europe Sàrl, Place Chauderon 18, CH-1003 Lausanne, Switzerland.

HOT (UK) Ltd, 1-4 Jessops Riverside, 800 Brightside Lane, Sheffield, S9 2RX United Kingdom.

©2016 Revlon. All rights reserved. (AW008675)

AW ISSUE No#: 1 Date: 03.18.16



# REVLON®

## Pediprep Spa

Including 9 piece nail care set

**RVFB7021PKUK**

# OPERATING INSTRUCTIONS

This appliance is intended for household use only.  
The appearance of this appliance may differ from the illustration.  
Only use this appliance for its intended purpose as described in this manual.  
Do not use attachments not recommended by the manufacturer.

## HOW TO USE

Place the appliance on a flat, level, solid floor.

## FILLING THE UNIT

1. Before filling the unit ensure that it is not plugged into the mains.
2. Fill the unit with water at the desired temperature.
3. The water level indicator on the inside of the footbath (maximum filling level of approx. 1.9 liters) should not be exceeded.
4. For any usage, the appliance should always be filled with water.

**NOTE:** This footbath cannot be used without water. It is NOT intended for dry operation.

## SWITCHING ON

1. Connect the appliance to the mains.
2. Sit in a comfortable position and then place your feet in the foot spa.
3. Always place your feet in the foot spa or remove them from the spa while in a sitting position.
4. Never use the appliance in a standing position or stand up in the unit, as too much pressure will cause the unit to crack.
5. To start the unit, depress the waterproof touch-toe button marked (⏻). The bubble jet strips will begin to emit bubbles.

Whilst the unit is turned ON, the unique 'keep warm technology' will help to slow the natural cooling of the water contained in the foot spa.

**NOTE:** The 'keep warm technology' feature avoids a rapid cooling down of the water. It is NOT suitable for heating cold water. You must begin with water at the desired temperature.

Refreshing bubbles in the water caress the feet gently and massage the skin.

Ten minutes daily is sufficient to feel refreshed. The length of the massage and the frequency of use can be increased if necessary.

## AFTER USE

1. When you have finished, turn the appliance OFF by pressing the waterproof touch-toe button marked (⏻) again, and remove the plug from the mains.
2. Hold the appliance on the sides of the unit and pour the water out.  
**NOTE:** The footbath should be emptied through the convenient draining spout opening at the front of the unit.

**CLEANING** - Rinse the unit with water and a mild cleaning liquid and dry. Wipe with a soft, damp cloth.

**DO NOT** use an abrasive cleaner. Keep away from all solvents and any harsh detergents.

**DO NOT** immerse the appliance in water.

## STORAGE - Always unplug when not in use.

Always store in a dry location. Do not pull or twist the cord. Do not wrap the cord around the appliance, as this may cause the cord to wear prematurely and break. Regularly check the power cord for wear and damage (particularly where it enters the appliance and the plug).

# FEATURES

- A. PEDICURE FOOT REST
- B. WATERPROOF TOE-TOUCH CONTROL
- C. REMOVABLE PUMICE STONE
- D. BUBBLE STRIPS
- E. MASSAGE ROLLER
- F. ACCUNODE MESSAGE PAD & ACCUNODE BASIN
- G. ANTI-SPLASH HOOD

