


USER MANUAL

FOR EasyBBQ nano L Smart Wireless BBQ Thermometer

Get to know the Device



Put in the Battery

- +**
CR2032
3V
- 1 Twist the battery cover counterclockwisely to unlock.
 - 2 Put in batteries, make sure the side with an icon of **+** is facing outside.
 - 3 Twist the battery cover clockwise to lock.

Download the APP

Search the keyword **'easybbq'** in Appstore or Google Play, or scan the following QR code with your phone. Download and install it for free.



Pair with your phone

- Status Indicator**
- 1 Press and hold the power button on the device for 3 seconds to power it on.
 - 2 Keep the blue-tooth switch of your phone on.
 - 3 Launch the app, and follow the instructions in the app to pair and activate the device:
Press the Pairing Button (in the back of the device);
Or, scan the bar code on the package or on the device.
 - 4 Connected successfully.

Once Paired the device with your phone, you don't need to do it again, unless you change to other phones.

Insert the device

Insert the probe into the food, make sure the front tip of the probe is in the center of the food to get accurate temperature.


DO NOT put the device directly in fire **flame**. Keep the main unit as far as possible to fire.



Enjoy your barbecue time

Choose food type and preference for the food where each probe is inserted, the app will display its current and tagert temperature.

When the food is ready, the app and the device will alarm.



The user interface of the app may be changed when update. Please follow the instructions in the app.

Power ON/OFF


Power ON:
Press and hold the power button for 3 seconds.

- Power OFF:**
- Press and hold the power button for 3 seconds, with the LED turning into white for 1 second.
 - Auto-off after 8 hours out of connection with phone.

WARNING

Putting the device directly in fire flame will burn it!

The device has limited water resistance, DO NOT wash the main unit in water! Please clean it with a wet cloth instead.



App Store is a service mark of Apple Inc.
Google Play is a service mark of Google Inc.



§15.19 Labelling requirements.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

§15.21 Information to user.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

§15.105 Information to the user.
Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct

the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

* RF warning for Portable device:
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.