

# CARE AND MAINTENANCE

## TROUBLESHOOTING

Please surveyed the massage chair when you are used it often.

Please checked up the massage chair when you no used for a long time .

SITUATIONS	SOLUTION
The massage chair doesn't work, ON/OFF and Restore key don't light up.	1.Check whether the plug is well connected and working well. 2.Check whether the switch on the massage chair is turnen to [I] positon.
Any sound during work.	Under those sound and feeling is normal phenomenon. 1. The sound when tapping and kneading. 2. The different after adjust speed. 3. Internal sound when massage. 4. Massage wheel grated on the cloth. 5. Expansive sound and exhaust sound during air massage. 6. The sound of vibrator. 7. The sound of adjust legrest. 8. The sound of motor when exert the wight of load.

## EMERGENCY TREATMENT

1. An exception occurred during the massage chair work,please close the switch and pull out the power line.

2. If the power line is broken,please notify our customer service to processing.

**Warning:** Except professional you don't dismantling,repair and change the massage chair,it may reduce electric shock and risk of fire.


## PRODUCT SPECIFICATION

MODEL NO.	TC-296
RATED VOLTAGE AND FREQUENCY	<input type="checkbox"/> 100~120V <input type="checkbox"/> 220~240V <input type="checkbox"/> 50Hz <input type="checkbox"/> 60Hz
RATED POWER	100W
DIMENSION (UPRIGHT)	L1260XW645XH1050(mm)
N.W.	55kg
ORIGINAL COUNTRY	CHINA
SERIAL NO.	

# tchair

## Massage Chair

TC-296



BE SURE TO READ THIS **INSTRUCTION MANUAL** CAREFULLY AND USE IT PROPERLY.  
 AFTER USE, KEEP THIS MANUAL WITHIN REACH AT ALL TIME FOR FUTURE USE.

# IMPORTANT SAFETY INSTRUCTIONS

## OPERATING SURROUNDINGS

- Do not use or store the massage chair under damp environment: i.e. bathroom, sauna, spa to avoid any moldy, electric shock, fire or mechanical failure.
- Don't use the massage chair outdoors.
- Don't use the massage chair under dusty, smearable and anoxic conditions.
- Don't place the massage chair near heater, stove or sunlight radiation to avoid inner components overheating to cause fire.
- Make sure to place the massage chair on a flat level ground.
- The bracket part should be placed on the plain ground.
- To avoid an electric shock, please make sure to connect an earth wire.
- Don't use the machine while smoking.



## FOLLOWING CONDITIONS SHOULD CONSULT DOCTORS BEFORE USE

- Suffered from malignant tumor.
- Serious heart disease.
- Serious skin disease.
- Serious boned hyperplasia.
- In pregnancy or during the menses.
- Be on the rest cure under the doctor's supervision.
- The back bended exceptionally by the accident or disease.
- Needing peaceful surroundings.
- Arthritis disease.
- Implanted pacemaker for medical purpose.
- Suffered from bowels disease.(i.e. gastritis, enteritis, diarrhea, hepatitis)
- Serious blood circulation trouble.
- Consciousness trouble.
- Be in hyper pyretic.

## WARNING

Children under 18 ages or special persons( as psychopath, the mental defects, the paralysis) close are not allowed to operate the massage chair, in case of electric shock, injuries or mechanism malfunctions.

# CARE AND MAINTENANCE

## STORAGE

- Do not remove the backrest form the chair ,touch the internal spare parts of massage chair may reduce electric shock.
- Do not remove the internal spare parts or repair the massage chair by yourself .It may reduce electric shock and risk of fire.
- Please pull out the power line when you are maintenance , if not it may reduce electric shock and hurt.
- The massage chair should keep clean all the time , and set in the dry place.
- If the massage chair not use for a long time ,please cover cloth to avoid dust.
- Avoid direct sunlight.







## THE MAINTENANCE OF MASSAGE CHAIR

- When you clean the massage chair please use neutral detergent and special detergent for clothing.
- If the backrest cushion , pillow cushion and legrest cushion are dirty ,please use neutral detergent and air seasoning.
- The plastic,piping and leather could use detergent ,then clean with dry cloth.
- Do not use abrasive cleaning agents like benzene or thinner to clean the controller, this may result in malfunction.
- Do not spray the insecticide to the massage chair,it may reduce electric shock and risk of fire.
- Please use dry cloth cleaning to avoid trouble.



## THE MAINTENANCE OF CONTROLLER

- Avoid source of heat and source of ignition.
- Keep dry and avoid electric circuit.
- Please cleaning by soft and dry cloth,and dust elimination by small banister brush.
- Prohibit the use of various volatile solvent. (i.e.tolueue ,oil,lacquer thinner etc.)

# OPERATION GUIDE

Button	Name	Function
	3D On/Off	Default normally open. The manual indicator lights up and the 3D massage turns on. The manual light is off and the 3D massage is off.
	Manual massage	Kneading, tapping, and shiatsu can be chosen.
	Air pressure	Three-stage air pressure adjustment. Preset value mid-range, gear cycle mid → low → strong
	Massage part selection	The massage area is selected as needed, and the manual massage is effective.
	Massage roller adjustment	Press button to move massage mechanism position up/down. This button is applicable to spot massage function.
	Angle adjustment	Press button to Angle adjustment. This button is applicable to spot massage function.

## End of the Massage

<p>On/Off</p> 	<p>Press the On/Off Button to disable all function before putting the remove controller into the controller pocket located at the back of the chair.</p>
	<ul style="list-style-type: none"> <li>· Turn off the power switch. ( to " O " )</li> <li>· Remove plug from power socket. (Please do not pull on the power cord to remove the plug.)</li> </ul>

# IMPORTANT SAFETY INSTRUCTIONS

For safety reasons and in order to clearly indicate potential dangers should the product be used improperly, instructions have been marked in the following manners and should be strictly noted.

## ⊘ CAUTIONS

**Non-professional technicians are not allowed to dismantle or repair to avoid fire, electrical shock or serious hurt.**



**Do not flush to the switch when cleaning to avoid insulation fault, electrical shock or short-circuit.**



**When storing or maintenance, be sure to disconnect the power plug from socket.**

Do not detach the plug by wet hands.



**Make sure to shut off and detach the power plug when cleaning or storing product.**

During cleaning or moving the machine, make sure to detach power cord to avoid fire or electrical shock.



**Do not place the machine onto an unstable surface to avoid roast, insulation failure, electrical shock or turnover.**

When storing the machine, make sure to disconnect power plug to avoid fire caused by electricity leaking.



**Clean power plug periodically to avoid fire due to dust.**



**Do not use it at any unsafe places or on other purposes.**

It is the main reason of product damage or accident.



**Do not store the machine onto an unstable surface.**

Unexpected earthquake or external force will cause damage or injury.



**Keep supply cord unobstructed at all time, i.e. not twisted, knotted, over flexed or pulled and do not place anything heavy on it.**



**Children should be supervised to ensure that they do not play with the appliance.**




**Cleaning and user maintenance shall not be made by children without supervision.**





# IMPORTANT SAFETY INSTRUCTIONS

## ⊘ CAUTIONS

**Do not modify the structure or change components by unauthorized person.**  
Do not dismantle the machine by unauthorized person to avoid electrical shock, short-circuit or fire. 

**Do not store it near a fire or flammable substances.**  
It is one of the reasons of causing product torture, deviation or damage. 

**Should any abnormality occur(i.e. scorching smell), stop using immediately and detach power plug from socket.**  
Keeping operating under an abnormal situation will cause fire or electrical shock, please contact your local seller or authorized service agent for maintenance. 

**Do not place the machine onto an unstable surface to avoid roast, insulation failure, electrical shock or turnover.** 

**Only rated voltage must be used.** 

**Stop using immediately if supply cord or power plug be damaged or loosen.** 





**Be sure to keep children away during operating to avoid any hazard.** 

**Do not explore it under sunshine at all time.** 


**This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.**

# OPERATION GUIDE

## Function Description of Remote Controller

Button	Name	Function
	On/Off Button	Turn on/off the massage chair.
	Pause	Stop all function operations. Press the button to continue.
	Automatic massage mode	<p><b>[Energy]</b> 'Shoulder neck / upper back = 70%' 'Lower back / hip = 30%' Deep massage for areas that are prone to fatigue throughout the day. First use the kneading technique to relax the body. Second by kneading / tapping technique allows comfortable neck. Third use kneading / tapping / shiatsu interlaced techniques to eliminate fatigue on the upper back. Then add hip and leg side pressure pneumatic release a full day of lactic acid accumulation.</p>
		<p><b>[Recovery]</b> 'Shoulder neck / upper back = 30%' 'Lower back / hip = 70%' Suitable for users who sit and stay for a long time. Sedentary / long standing blood will concentrate on the lower body. Reduce the pressure on the lower body through the chair's reclining angle. Use the kneading/ tapping technique and the hip and leg pressure to relieve the fatigue of the whole day. The calf roller can soothe the tight calf all day and instantly eliminate soreness. Buttocks massage can feel your seat all day hip muscles to relax.</p>
		<p><b>[Cradle]</b> 'Shoulder neck / upper back = 50%' 'Lower back / hip = 50%' Unique cradle function. Acupressure and movement wide/medium/narrow up and down movement, let the user feel the real hand massage. Plus the massage chair swings back and forth slowly, let the user completely relax as if returning to the rattan rocking chair. Get full diastolic pressure and relaxation on it.</p>
		<p><b>[Sleep]</b> 'Shoulder neck / upper back = 50%' 'Lower back / hip = 50%' Calf roller cancel. Slow and gentle mobile massage to soothe tired body. The reclining angle is ergonomically the most comfortable angle, let the body relax quickly get. This program is lower than the intensity of the three automatic massage programs, suitable for light massage users. The user can adjust the use to achieve the best results of the massage.</p>
	Heating	Both sides of the lower back and the sides of the calves. Heating ON / OFF.


## OPERATION GUIDE



※ In the standby state, press and hold the 3D button for 2-3 seconds to turn off the button beep. To start the button beep, please reboot.


## PARTS NAME

■ Side View




## PARTS NAME

### Rear View




## PREPARATION FOR USE

### 1. Remove the package and take out the chair and spare parts



- 1.) Remove the carton. Take out the chair.
- 2.) Install the pillow and backrest cover.


### 2. Place the massage chair in an open area



- \* Allow sufficient space around the chair for rolling purposes.
- \* To avoid damage to the floor and to reduce the noise, please put a rug under the chair.
- \* Make sure that there is no barrier at the front and the back of the chair.
- \* Please do not put the chair on wet or uneven floor.
- \* To avoid signal interference, please place the chair 1 meter away from TV and radio.

**Warning:**  
Do not put the power cord under the chair!

### 3. Move the massage chair



- 1.) As illustrated, push the backrest downwards and tilt chair on to its wheels at a 45° angle.
- \* Slowly push and move the chair to the desired location. Lower the chair slowly and smoothly until it is fully flat on the ground.

**Warning:**

- \* Do not move the chair when occupied or in use.
- \* Moving the chair may cause damage to the floor. Floor protection is recommended. (e.g. rugs or carpet)
- \* Do not drop or suddenly let go of the chair when moving as it may damage the chair.
- \* Two persons are recommended when moving the chair and extra care is required.