


# Video Borescope Inspection Camera

Model BR80



## Introduction

---

Congratulations on your purchase of the Extech BR80 Video Borescope. This instrument was designed for use as a remote inspection device. Typical applications include HVAC inspection, automotive inspection, cable routing, and boat/aircraft inspection. This meter is shipped fully tested and, with proper use, will provide years of reliable service.


## Cautions

- Do not expose the handle and display to spraying water.
- Switch off the Camera if the system is not in use.
- Please dispose of the batteries responsibly.
- Remove the batteries when cleaning the unit.
- Remove the batteries before storing the unit for an extended period of time.
- When batteries need replacement, replace all four of the batteries.
- Use only the specified battery size and type.
- Be sure to install the batteries with the correct polarity as indicated in the battery compartment.
- Exposure to high temperatures can cause the batteries to explode, therefore do not dispose of the batteries in fire. Place tape over the terminals to prevent direct contact with other objects. Please follow all applicable regulations.

## Description

---

- 1 Camera tube connector
- 2 Battery status indicator
- 3 Display monitor
- 4 Camera light intensity (+) button
- 5 Image rotation button
- 6 Flexible camera tube
- 7 Battery compartment (bottom of handle)
- 8 Camera and LED lights
- 9 Handle grip
- 10 Power button
- 11 Camera light intensity (-) button



## **Safety and Care**

---

- Do not expose instrument (display) to moisture
- Switch off the instrument when not in use
- Remove the batteries when cleaning the instrument
- Replace all of the batteries at the same time
- Do not immerse the camera in water
- Store in a dry place
- Only the camera head and the flex tube are water resistant

### **Warning**

Permanent damage to the flex tube and loss of operation will occur if the flex tube is subjected to narrow radius or sharp angle bends.

## **Battery Installation**

---

1. Open the battery compartment by sliding the latch at the bottom of the instrument's handle
2. Insert four new 'AA' 1.5V batteries into the proper slots in the battery compartment. Proper battery orientation is indicated on the battery compartment.
3. Close the battery compartment.



**Note:** Do not mix old and new batteries. Do not mix alkaline, standard (Carbon-Zinc), or rechargeable (Nickel Cadmium) batteries.



Never dispose of used batteries or rechargeable batteries in household waste. As consumers, users are legally required to take used batteries to appropriate collection sites, the retail store where the batteries were purchased, or wherever batteries are sold.

**Disposal:** Do not dispose of this instrument in household waste. The user is obligated to take end-of-life devices to a designated collection point for the disposal of electrical and electronic equipment.

## Operation

---

### Connect the monitor and flexible tube

Connect the camera tube to the instrument body. Ensure that the keyed ends are properly aligned. Once aligned, tighten the knurled knob to hold the connection firmly in place.


### Start-up

1. Press the power button to switch the camera ON; if there is sufficient battery power the power indicator will illuminate and an image will appear on the LCD.
2. Insert the camera head and the flexible tube into the area to be viewed. Pre-shape the tube when inserting into areas with bends and curves.

### LED intensity:

Four LEDs mounted on either side of the camera are used to illuminate the inspection area. Use the left (minus) and right (plus) illumination buttons to adjust the intensity. To switch the illumination off, continue to press the left (minus) button until the illumination switches off. There are 100 discrete intensity levels.

### Image Flip

Press the  button to flip the image. The figure to the right demonstrates how the image is adjusted for each button press.




FLIP



FLIP

### Auto Power OFF (APO)

APO automatically switches the meter off to extend battery life. To change the APO setting, press and hold the flip  button until the 'Clock' icon appears. Use the flip button to step through the selections (OFF, 5 minutes, and 10 minutes). The meter will return to normal operation after 3 seconds. If 5 or 10 minute APO is enabled, the clock icon will appear in the display.

### Battery Status Indicator

The rectangular light at the top of the display area is the battery status indicator. When the indicator is red in color, the batteries are weak. When the indicator appears green in color, the batteries are charged.

### Warning

Permanent damage to the flex tube and loss of operation will occur if the flex tube is subjected to narrow radius or sharp angle bends.

### Accessory tools

The included accessories (mirror, hook and magnet) all attach to the camera head. Snap the tool clip into the recessed area on the camera assembly.

## **Specifications**

---

Imaging Sensor	CMOS
LCD Screen Type	2.36" TFT-LCD
Pixels	480 x 234
Horizontal View Angle	50 degrees
Working length	1m (39")
Camera head diameter	17mm (0.67")
Shaft diameter	9mm (0.35")
Focus length	5.1 cm (2")
Auto Power OFF (APO)	OFF /5 min. /10 min. selectable
Waterproof Capacity	IP67 (imager head and tube)
Power Supply	4 x 'AA' 1.5V batteries
Consumption Current (Max.)	150mA
Dimensions	211 x 83 x 76mm (8.3 x 3.3 x 3") meter body only
Weight	0.61 kg (1.35 lbs) (meter & tube)
Operating Temperature	-10°C~+50°C (+14°F~+122°F)
Operating Humidity (Display)	15~85%RH

**Copyright © 2013-2017 FLIR Systems, Inc.**

All rights reserved including the right of reproduction in whole or in part in any form

**ISO-9001 Certified**

**[www.extech.com](http://www.extech.com)**