

# ELYSIAN

# E



[hello@elysianwatches.com](mailto:hello@elysianwatches.com)

# THANK YOU FOR YOUR PURCHASE!

The company is young and still growing. We strive for high quality watches at an affordable price. Our main goal is to satisfy our customers.

We hope you will enjoy your Elysian watch as much as we do. Please feel free to contact us if you have any feedback, we highly appreciate it.

Follow us on social media!




[@elysianwatches](#)




[@elysianwatches](#)


# ADJUSTING THE MESH STRAP



1. Open the top clasp. Insert the adjustment tool in the slot and lift it up.



2. Slide the buckle in the desired position.



3. Insert the adjustment tool back into the slot and lock it down towards the strap.

# WATER RESISTANCY

If your watch is not marked, usually on the back of the case, with either the words “Water Resistant” or a degree of water resistance (3ATM), please avoid all contact with water.

## Water resistant 3ATM:

This means the watch is NOT made for swimming, diving, bathing or showering. It is only protected against minor contact with water. Excessive contact with water may cause damage to the watch. Water leakage and/or damage caused under these circumstances will not be covered by the guarantee.

# WARRANTY

Your watch has a limited two-year warranty beginning from the date of purchase. This warranty covers manufacturing defects. This means the inner parts (mechanics) of the watch. The warranty does not cover theft, abuse, water damage, batteries, glass damage, strap damage and normal wear and tear.

Should your watch display manufacturing defects, please contact our support team. You can email us at [support@elysianwatches.com](mailto:support@elysianwatches.com) or visit our website for more information. Proof of purchase is always required for all warranty claims.