


# **X** *EXPLORERS GYROSCOPE 2.4G* **5S/X5SG** 4CH 2.4G REMOTE CONTROL QUADCOPTER

BC



## 1 **INSTRUCTION MANUAL**

IMPLEMENT STANDARD: GB/T26701-2011

### Main characteristics

- Four-axis structure is applied, which makes the quadcopter more flexible and rapid when flying. It has the characteristics of wind-resistant and can be flown indoor or outdoor.
- Built-in 6 axis gyroscope for precise hovering in the sky.
- Modular design structure is applied, more simple for assembly and convenient for maintenance.
- With 360° 3D eversion function and throwing flight function.
- Newly-increased headless function can recall the aircraft easily.

The materials and specification mentioned in this instruction manual or the parts inside this package is for reference only. Our company won't be responsible for any adaption of the outer package. Nor shall we keep our customers informed in advance. Any information updates or changes, please be subject to our website

## Safety regulations

1. Please put smaller parts of the aircraft in the place where children can't reach, avoiding from accidents.
2. Power of this aircraft is adequate. Therefore, when flying for the first time, it should push remote control's right/left variable-speed joystick slowly, avoiding from collisions caused by rising aircraft rapidly.
3. After flying, it should turn off remote control's power supply and come close to the aircraft to turn off its power supply.
4. Please don't put battery in high-temperature and heated places(such as fire or nearby electric heating devices).
5. When the aircraft flies, it should maintain 2-3 meters from the user or others, avoiding from crashing into others' head, face or body when it lands.
6. When children operate the aircraft, they should be accompanied with the adult and guided by the adult. Ensure that the aircraft is controlled within the range of operator's (or instructor's) visibility. It is convenient for controlling.
7. Non-rechargeable battery can't charge. As installing or changing battery, please pay attention to the polarity. Don't use a mixture of old and new battery or battery with different types.
8. When it isn't used, it should turn off remote power supply of remote control and aircraft, respectively, and take out the battery in remote control.
9. Power supply terminal can't be short circuit.

## Maintenance

1. Use clean soft cloth to clean this product frequently.
2. Avoid from exposure or heating in the sun.
3. Don't put the toy in the water. Otherwise, it'll damage electronic parts.
4. Please check the plug and other accessories at regular intervals. If there is any damage, please stop using it immediately until it is repaired completely.

## Contents


Product included following contents:

- Quadcopter
- Four riggers
- 2.4G Remote controller
- Four foot stands
- USB charging wire
- Instruction manual
- Screwdriver
- Blade(4 pieces)
- Camera(X5SC)
- Reader



## Get to know your transmitter

### Introduction of transmitter:





Installation methods of battery: Open back battery cover of remote control, and put 4 No.5 alkaline batteries in the middle place correctly, according to battery box's pole indication (battery should be available separately).



1. Install batteries with correct polarity.
2. Do not mix old and new batteries.
3. Do not mix different types of batteries.

## Remote control keypad and lcd manual



- 01.Sideward Fine-tuning :Power-on start in the centering.(Be turn Left/Right Fine -tuning in Mode2)
- 02.Forward/Backward fine-tuning:Power-on start in the middle.
- 03.Turn Left/Right fine-tuning:Power-on start in centering.(Be Sideward Fly Fine -tuning in Mode2)
- 04.Forward shows:Power-on start in the lowest level.(At the center square)
- 05.Backward shows:Power-on start in the lowest level.(At the center square)
- 06.Right sideward fly shows:Power-on start in the lowest level.(At the center square)
- 07.Left sideward fly shows:Power-on start in the lowest level.(At the center square)
- 08.Turn left: Pull left function lever to left, it will be higher, than quad copter turn left faster.
- 09.Turn right: Pull left function lever to right, it will be higher, than quad copter turn right faster.
- 10.High/Low speed: Press button "A" for seconds to switch between high speed mode or low speed mode. "H" means high speed and "L" means low speed.
- 11.Power shows:According to the battery's energy for the controller.
- 12.Default mode when power-on.When change to MODE 2, please keep pressing button "B" to right than return on the power of transmitter, the MODE on LCD displayer will be changed. Same steps to change to MODE 1 again.
- 13.Signal shows:Normally to full frame.

## Install landing skids & blade protecting frame



Figure 1

1. Insert foot stands into interface of lower main body as shown in Figure (1).




Figure 2

2. Install the blade protecting frame to every corner than lock screws (Figure 2-3).



Figure 3

## Install camera

Installation steps of camera:



Figure 1



Figure 2

1. Push the camera in place as shown in Figure (1).
2. Connect connecting line of camera with power supply socket of fuselage's camera as shown in Figure (2).

Disassembly steps of Camera:



Figure 1



Figure 2



Figure 3

1. Pull out power supply cable of the camera as shown in Figure (1).
2. Press down safe lock of lower main body as shown in Figure (2).
3. Push forward the camera and take it out as shown in Figure (3).

## Controller modes & instructions


The transmitter built-in two modes, Mode 1 & Mode 2, in line with different customer's usage pattern. Keep pushing button B to right, then turn on the transmitter power to change Mode 1 or Mode 2.



### MODE 1


#### Operating direction

Hover up and down




Push the throttle up or down, the quadcopter flies upward or downward.

Forward and backward




Push the direction lever up or down, the quadcopter flies forward or backward.

### Turn Left and Right



Pull the throttle left or right, the quadcopter turns to left or right.


### Sideward fly



Pull the direction lever left or right, the quadcopter flies to left side or right side.

## Fine-tuning operation

### Forward/Backward fine-tuning




When the quadcopter keeps flying forward / backward, you can correct it by pressing fine-tuning button down / up.

### Sideward fly fine-tuning



When the quadcopter keeps flying to left / right side, you can correct it by pressing the Fine-tuning button right / left.

### Turn left/right fine-tuning




When the quadcopter keeps rotating to left / right, you can correct it by pressing the fine-tuning button right / left.

## MODE 2


### Operating direction

#### Hover up and down




Push the throttle up or down, the quadcopter flies upward or downward.

#### Forward and backward




Push the direction lever up or down, the quadcopter flies forward or backward.

### Turn Left and Right



Pull the direction lever left or right, the quadcopter turns to left or right.

### Sideward fly



Pull the throttle left or right, the quadcopter flies to left side or right side.


### Fine-tuning operation

#### Forward/Backward fine-tuning




When the quadcopter keeps flying forward / backward, you can correct it by pressing fine-tuning button down / up.

#### Sideward Fly fine-tuning



When the quadcopter keeps flying to left / right side, you can correct it by pressing the Fine-tuning button right / left.

#### Turn left/right fine-tuning



When the quadcopter keeps rotating to left / right, you can correct it by pressing the fine-tuning button right / left.

### Ready to fly your quadcopter



1. Press the ON/OFF power switch up.



2. Open battery cover, and connect battery connector with dash receiver.



3. Enclose battery into the fuselage, after closing battery cover, turn on the switch on the bottom of aircraft.



4. Push the throttle lever to the highest position, and then pull it back to the lowest position. There will be one clear sound from the transmitter, this shows that the quadcopter has entered into the pre-fly state.

## Function introduction

### 1. Low-voltage protection:

When four indicator lights on the bottom of aircraft start to flicker, it means electric quantity of the aircraft is insufficient. Please control the aircraft to make a return voyage.




### 2. Low-voltage protection:

When four indicator lights on the bottom of aircraft start to flicker, it means electric quantity of the aircraft is insufficient. Please control the aircraft to make a return voyage.



### 3. Horizontal correcting function:


Place the quadcopter on a horizontal position, then push transmitter both left and right lever to lowest right corner for about 2-3 second, indicator on the quadcopter changed from normal lights up to quickly flashing; After 2-3 second, the indicator changed to normal lights, it means the quadcopter restarted /reset successfully.



### 4. 3D eversion:

When you are familiar with the basic operation, you can do some awesome & exciting tricks and stunts! First of all, fly the aircraft to a height of more than 3 meters, press the 3D Eversion switch on the rear right side of the transmitter, then push the right rudder (in any direction) to make 360 degree flip.

**Tips.** 3D eversion goes better when battery power is enough.





## 5. Photography/video instructions:

1. Methods: ① Make sure the 3-pin plug of camera is inserted to the quadcopter  
② Turn the quadcopter power on, the camera works normally when the RED indicator change form flashing to green and keep light on. If the RED indicator just light on and light off seconds later, it means the SD card is not in the camera. Please insert the SD card, than the indicator light on GREEN.



## 2. Get to know take photo and video:

- ① Turn on the transmitter and pull left lever up and down to connect signal between quodcopter and transmitter.


## 6. Throwing flight instructions:

Thanks to the 6 axis gyroscope, you can throw the quadcopter and push the throttle right up, it will automatically level out and hover smoothly in the sky, This can also be done when the quadcopter isrolling.




## 7. Headless function:


### 1. Forward definition



1. Turn on power switch of remote control.




2. After aircraft connects with power supply, place the switch in "ON" position, adjust the direction pointed by aircraft's handpiece and regard it as the dead ahead in headless situation.




3. Push the accelerator's push rod of remote control to the highest point and pull back to the lowest point. When remote control pops, it indicates that frequency modulation and forward definition have already finished.

## 2. Switch to headless function and general function



1. After frequency modulation, the aircraft defaults to general pattern. The indicator light on aircraft is long bright state. After pressing down headless function switch on the top left of master remote controller for 2 seconds, remote control will give out "DDD...", it means that it enters into headless state. After pressing for 2 seconds and hearing long "D", it means that it exits headless state. (In headless mode, four indicators on the aircraft flicker slowly for once within four seconds)



2. In headless state, the operator has no need to recognize the position of aircraft's headpiece, and he just needs to control the aircraft in accordance with the direction of remote control's operating rod.

## 3. Correcting forward direction



1. After aircraft crashes in headless state, if there is deviation in head direction, it just needs to adjust the aircraft's direction again, pull remote control's accelerator and operating rod to bottom left simultaneously. When indicator light on the aircraft flickers for slow three seconds, it means that correction is done.

## Change battery of quadcopter



1. Push the on/off switch of quadcopter to OFF position than open the battery cover.



2. Pull out the battery wire from the power port.



3. Take out the USB charging cable, and insert the battery power port to the small end of it (Make sure the ports connect tight and correct ).



4. To charge battery, please insert the USB port of provided USB charging cable to anyone USB port of computer.

The indicator on USB cable will light ON during charging battery, than it will light OFF when battery fully charged.

Caution:

When using the computer for charging, please remember to pull out the charging cable before shutting down the computer. Take the battery cover, and close the battery cover on the quadcopter.



5. Reconnect the battery wire to power port than close the battery cover.

Charging time: about 130 minutes — Flying time: about 5.5 minutes!

### Cautions when charging:

1. When charging, please put this product on a dried or ventilated area and keep it far away from heat source or explosive product.
2. When charging, please remove the batteries from the quadcopter. Then charging process should be supervised by an adult so as not to cause an accident.
3. After flying, please do not charge the battery if the surface temperature is still not cool. Otherwise it may cause a swollen battery or even a fire hazard.
4. Please make sure that you use the original USB charging cable provided. When the battery has been used for a long time, or appears to be swollen, please replace them.
5. A battery when not in use for a long time will lose its charge automatically. Charging or discharging too often may reduce the life of the battery.

### Maintenance procedure

| Problems                                     | Causes  | Solutions   |
|--|---|---|
| Aircraft has no response                     | <ol style="list-style-type: none"><li>1. Aircraft enters into low-voltage protection.</li><li>2. Electric quantity of remote control is insufficient, power indicator light will flicker.</li><li>3. Channel selection of remote control is inconsistent with aircraft's match codes.</li></ol> | <ol style="list-style-type: none"><li>1. Charge the aircraft.</li><li>2. Change remote control's battery.</li><li>3. Adjust channels of remote control and aircraft, and make them become consistent.</li></ol> |
| Aircraft's flying response is insensitive    | <ol style="list-style-type: none"><li>1. Insufficient remote control's electric quantity.</li><li>2. Remote control with the same frequency is transmitting interference.</li></ol>   | <ol style="list-style-type: none"><li>1. Battery replacement.</li><li>2. Change the place where has no transmitting interference of the same frequency.</li></ol>   |
| When hovering, side flight is formed         | <ol style="list-style-type: none"><li>1. Have no horizontal correction.</li></ol>   | <ol style="list-style-type: none"><li>1. Conduct horizontal correction, as shown in p.7(3)(correcting function)</li></ol>   |
| In headless state, it deviates to dead ahead | <ol style="list-style-type: none"><li>1. Head deflection is caused by multiple collisions.</li></ol>  | <ol style="list-style-type: none"><li>1. Define forward again, as shown in p.8-9(7)(headless function)</li></ol>  |

## X5S Spare parts

Here are alternative accessories. In order to provide convenience for customer purchasing, every component are marked. Accessories can be purchased from local dealer. Please specify the color when purchasing.



X5S-01A  
Fuselage-white



X5S-01B  
Fuselage-black



X5S-02A  
Blades-white




X5S-02B  
Blades-black



X5S-03A  
Landing skids  
-White



X5S-03B  
Landing skids  
-black



X5S-04  
Protecting  
frames



X5S-05  
Lampshades



X5S-06  
Motor A



X5S-07  
Motor B



X5S-08  
Light boards



X5S-09  
Receiver  
board



X5S-10  
Battery



X5S-11  
USB



X5S-12  
Transmitter

## X5SC Spare parts

Here are alternative accessories. In order to provide convenience for customer purchasing, every component are marked. Accessories can be purchased from local dealer. Please specify the color when purchasing.



X5SC-01A  
Fuselage-white



X5SC-01B  
Fuselage-black



X5SC-02A  
Blades-white



X5SC-02B  
Blades-black



X5SC-03A  
Landing skids  
-White



X5SC-03B  
Landing skids  
-black



X5SC-04  
Protecting  
frames



X5SC-05  
Lampshades



X5SC-06  
Motor A



X5SC-07  
Motor B



X5SC-08  
Light boards



X5SC-09  
Receiver  
board



X5SC-10  
Battery



X5SC-11  
USB



X5SC-12  
Camera




X5SC-13  
Reader





X5SC-14  
Transmitter

## Brerkdwn&Diagram



| Code | Description       | Quantity | Code | Description    | Quantity | Code | Description   | Quantity |
|------|-------------------|----------|------|----------------|----------|------|---------------|----------|
| 01   | Upper body        | 1        | 08   | Receiver motor | 2        | 15   | Landing skids | 4        |
| 02   | Lower body        | 1        | 09   | Receiver board | 1        |      |               |          |
| 03   | Rotating blade    | 2        | 10   | Lampshades     | 4        |      |               |          |
| 04   | Reversing blade   | 2        | 11   | Light boards   | 4        |      |               |          |
| 05   | Protecting frames | 4        | 12   | Battery        | 1        |      |               |          |
| 06   | Battery cover     | 4        | 13   | Gear           | 4        |      |               |          |
| 07   | Rotating motor    | 2        | 14   | Camera         | 1        |      |               |          |

## MAIN PARAMETER



Body length: 31.5cm

Body width: 31.5cm

Body high: 10.5cm

Main motor code:  $\phi 8$

Battery: 3.7V 500 mAh Li-poly



SPECIFICATIONS AND COLORS OF CONTENTS MAY VARY FROM PHOTO.

The company has the right of final interpretation of this instruction manual statement.