

OWNER'S MANUAL



CE FC 

Warning

WARNING: Riding an electric scooter can be a dangerous activity. Certain conditions may cause components to fail without fault of the manufacturer. Scooter can and is intended to move and it is therefore possible to lose control, fall off and/or get into dangerous situations that no amount of care, instruction or expertise can eliminate. If such a thing does occur you can become seriously injured or die, even when using safety equipment and other safety precautions. **RIDE AT YOUR OWN RISK AND ALWAYS USE COMMON SENSE.**

This manual contains many warnings and cautions concerning the consequences of failing to inspect, maintain or properly use your electric scooter. Since any incident can result in serious injury or even death, we do not repeat the warning of possible serious injury or death each time such a possibility is mentioned in this manual.

APPROPRIATE RIDING CLOTHING

Always wear proper protective equipment such as:

Approved safety helmet. (Helmet may be legally required by local law or regulation in your area.)

Elbow pads and knee pads

Long sleeved shirt, long pants

Gloves

Lace up shoes with rubber soles, never ride barefooted or in sandals, and insure that shoelaces are tied and kept out of the way of the wheels and drive system.

RIDER USE AND PARENTAL SUPERVISION

RIDER MUST NOT EXCEED THE WEIGHT LIMIT OF 110 pounds (50kg). Rider weight does not always mean a person's size is appropriate to fit or maintain control of the scooter.

This manual contains extremely important safety information. It is your responsibility to completely review this information and make sure that all riders understand all warnings, cautions, instructions and safety topics and assure that all riders are able to safely and responsibly use this scooter. We advise that you periodically review and reinforce all information in this manual with all riders, and that you inspect and maintain your scooter to insure their safety.

The recommended rider age is 8 and older. Any rider that is unable to fit comfortably on the scooter should never attempt to ride it. A parent's decision to allow their child to use scooter should be based on the child's maturity, skill and their ability to follow rules.

Do not touch the motor or brakes on the scooter when in use or directly after use as these parts can become extremely hot.

Keep this scooter away from small children and remember that it is intended for use only by persons who are, at a minimum, completely competent and comfortable while operating this product.

RIDING PRACTICES AND CONDITIONS

Check and obey any local laws or regulations which may affect the locations where the electric scooter may be used.

Always ride defensively. Watch out for obstacles that could catch your wheel or force you to turn

suddenly or lose control. Be careful to avoid pedestrians, other wheeled products (such as scooters, skateboards, scooters, bikes, etc.), children or animals who may enter your path. Always respect the rights and property of others.

Do not activate the speed control on the hand grip unless you are on the scooter and in a safe, outdoor environment that is suitable for riding.

Do not attempt or perform stunts or tricks on this electric scooter. This product is not made to withstand abuse from jumping, curb grinding or any other type of misuse or stunts.

Maintain a hold with both hands on the handlebars at all times. Never allow more than one person at a time to ride the scooter. Never use near steps, water, or swimming pools.

Keep your fingers and other body parts away from the belt, motor, steering system, wheels and all other moving components.

Never ride while using a cell phone or wearing headphones.

Never hitch on to or with another vehicle or pull anyone or anything.

Never immerse the scooter in water; electrical and drive components could be damaged by water or create other possible unsafe conditions.

Ride only on flat, dry surfaces such as pavement or level ground without loose debris, such as sand, leaves, rocks or gravel. Water, mud, ice, bumpy, uneven, slick, or rough surfaces could impair traction and contribute to possible loss of control. Avoid excessive speeds that can occur from downhill rides which could cause loss of control.

Do not ride at night or in areas of limited visibility.

Do not ride indoors or on surfaces that could become damaged such as carpet or flooring.

Before each cycle of operation, the operator shall perform the preoperational checks specified by the manufacturer; that all guards and pads originally supplied by the manufacturer are in proper place and in serviceable condition.

That any and all axle guards, chain guards, or other covers or guards supplied by the manufacturer are in place and in serviceable condition.

Persons with the following conditions shall be cautioned not to operate. Those with heart conditions, pregnant women, persons with head, back, or neck ailments, or prior surgeries to those areas of the body. Persons with any mental or physical conditions that may make them susceptible to injury or impair their physical dexterity or mental capabilities to recognize, understand, and perform all of the safety instructions and to be able to assume the hazards inherent in unit use.

Maximum operating speed is 10 MPH (16 KMH) ; 250W Motor, Max speed is 15kmi/h.

Before each ride the following checks will need to be performed in the scooter.

Ensure that the brake system is functioning properly.

That all components are properly secured and are functioning according to manufacturer specifications.

Components shall be maintained and repaired in accordance with the manufacturers authorized replacement parts with installation performed by dealers or other skilled individuals.

USING THE BATTERY CHARGER

The battery charger should be regularly examined for damage to the cord, plug, enclosure and other parts. In the event of such damage, if any is found, the scooter should not be charged until the battery charger has been repaired or replaced.

Use only with the supplied recommended battery charger.

Always use caution when charging.

The battery charger is not a toy and should be operated by an adult.

Never operate battery charger near flammable materials or liquids.

Disconnect the battery charger and unplug from scooter when not in use.

Do not exceed recommended charging time.

Always disconnect the battery charger from the scooter prior to wiping down and cleaning with any liquid.

FAILURE TO HEED TO THE WARNINGS LISTED ABOVE INCREASES RISK OF POTENTIAL SERIOUS INJURY. USE THE APPROPRIATE CAUTION WHEN RIDING AND ALWAYS WEAR PROTECTIVE GEAR.

Hardware Maintenance

Brake

Check the brakes for proper function. When you squeeze the lever, the brake should provide positive braking action. When you apply the brake with the speed control on, the brake cut off switch should stop the motor. Make sure that the brakes are not rubbing when lever is not being applied.

Frame, Fork and Handlebars

Check for cracks or broken connections. Although broken frames are rare, it is possible for aggressive rider to run into a curb or wall and bend or break a frame. Get in the habit of inspecting your scooter on a regular basis.

Tires

Periodically inspect the wheels for excess wear and always check and maintain tire inflation.

Safety Gear

Always wear proper protective gear such as an approved safety helmet. Elbow pads and knee pads are recommended. Always wear athletic shoes (lace up shoes with rubber soles), never ride barefooted or in sandals, and keep shoelaces tied and out of the way of the wheels, motor and drive system.

Battery

Make sure the power switch is turned off whenever the scooter is not in use. Never store the product in freezing or below freezing temperatures! Freezing will permanently damage the battery.

Before You Ride

Before you ride always check and for the following: Safety Gear

Always wear proper protective gear such as

Approved safety helmet. (Helmet may be legally required by local law or regulation in your area.)

Elbow pads and knee pads

Long sleeved shirt, long pants

Gloves

Lace up shoes with rubber soles

Brake

Check the brakes for proper function. When lever is squeezed it should slow/stop the rear wheel without excessive effort. When you apply the brake with the throttle on, the brake cut off switch should stop the motor. Make sure that the brakes are not rubbing when the lever is not being squeezed. Do not ride the scooter if the brakes are not functioning properly.

Throttle

Make sure that before throttle is twisted that you are in an open and safe area to ride, you are balanced on the scooter and have both hands on the handlebar controls.

Tires

Inspect the wheels for excess wear and replace if necessary. Always check and maintain tire inflation.

Frame, Fork and Components

Always carefully inspect your scooter before you ride. Check for cracks, broken, worn or loose components which should be repaired or replaced before you ride.

Battery

Always make sure the power switch is in the "Off" position whenever the scooter is not in use. Never store the product in freezing or below freezing temperatures. These low temperatures will permanently damage the battery.

Assembly



1. Connect rear parts of frame and main frame and tight screws on the rear and main frame.



2. Place seat on the frame. Confirm 4 holes on the seat consistent to holes on the frame.



3. Put main frame into front fork connection parts. Make sure limit nut on the main frame on the parallel line to front tube groove. Insert steering bolt and tighten.



Product Specifications (Battery and Motor is Options)

| NO | 1 | 2 | 3 |
|-----------------------|---------------------|---------------------|---|
| Motor | 12v 100W | 12v 100W | 36v 250W hub motor |
| Battery | 12V 4.5AH Lead acid | 12V 8AH Lead acid | 36v lithium battery |
| Brake | front brake | front brake | Front drum brake |
| Throttle | Button throttle | Button throttle | Holder turn (Three speed can be adjusted) |
| Front wheel | 200x50 Rubber Wheel | 200x50 Rubber Wheel | 200x50 Free inflation |
| Rear wheel | PU Flashing wheel | PU Flashing wheel | PU Flashing wheel |
| Max speed | 10km/h | 10km/h | 8-25km/h |
| Range per charge | 5km | 10km | 15-20km |
| Max Loading | 40kg | 40kg | 75kg |
| Charge time | 3-5h | 3-5h | 4-6h |
| Product Size | 95x60x60 cm | 95x60x60 cm | 95x60x60 cm |
| Seat to ground height | 6cm | 16cm | 15cm |
| Packing size | 71x58x23 cm | 71x58x23 cm | 71x58x23 cm |
| N.W/G.W | 14/16kg | 14/16kg | 13/16kg |