

Mercedes-Benz AROCS 6x4



www.youtube.com/user/Amewicom

8 HAGES



Specifications: Size: approx. 422 x 152 x 181 mm Weight: approx. 3600g Battery: 7.2V 400mAh, JST connector Remote controller battery: 4 x AA batteries (not included) Playing time: approx. 20 minutes Control distance: about 30m Channel: 10 Function: forward, backward, left-turning, right-turning, bucket push

(load 10kg, self-unloading 4kg)

Declaration of Conformity

This product has been manufactured according to actual technical standards. The product is matching the requirements of the existing european and national guidelines. The Declaration of Conformity has been proofed. AMEWI Trade e.K. declares that this product is matching the basic requirements and remaining regulations of the guideline 2014/53/EU (RED). The declarations and documents are stored at the manufacturer and can be requested and applied there.

The full text of the declaration of conformity can be found at: https://amewi.com/de/downloads/index/search/

For additional questions to the product and conformity please contact: AMEWI Trade e.K., Nikolaus-Otto-Str. 18, DE-33178 Borchen, Fax: +49 (0)5251 / 288965-19, Email: info@amewi.com.

Security and Hazard Warnings

Attention! For damage, caused by disregarding of the manual, warranty expires!

We are not liable for secondary failures, material or personal damage, caused by inproper usage or disregarding

Attention! Based on security and registration (CE) reasons, it is forbidden to modify the product personally. Do

Attention! Small parts. Danger of suffocation or risk of injury caused by small parts.



The product is not allowed to get moist or wet. The product is only allowed to be used on flat and clean surfaces. Even a drop down from a small height can cause damage to the product. Usage of more then one Products of same Frequency at the same time is not possible, because it will affect each other.

Battery Notice and Battery Disposal

Attention! Battery do not belong in childrens hands. A change of the battery has to be done by an adult person. Never mix chargable batteries with non-chargable batteries. Never mix fully charged batteries with almost emtpy batteries. Never mix batteries of different capacities. Never try to charge dry batteries. Take care of the correct polarity. Defective batteries belong to special waste. Never leave a charging battery unattended. For questions about the charging time please read the manual or ask the manufacturer.

Disposal

The company AMEWI is registered below the WEEE Reg. Nr. DE93834722 at the foundation EAR and recycles all used electronic parts properly. Electric and electronical products are not allowed to put in household garbage. Please dispose the product at the end of the lifetime accroding to the actual laws. You as a customer are responsible by law for the return of all used batteries, a disposal over the household garbage is forbidden!



prohibition of disposal in household garbage.

Batteries containing hazardous substances are marked with the alongside symbols, which point to the

Additional notations for the critical heavy metal are: Cd=Cadmium, Hg=Quecksilver, Pb=lead (Label is placed on the batteries, for example below the bottom left trash symbols).



Based on RoHS labeling the manufacturer confirmes, that all limit values were taken care of at the time of manufacturing.

Batteries labeled with the recycling symbol can be put into used battery collecting tank.



They are not allowed to be put into local household garbage. AMEWI Trade e.K. is involved in the dual system for boxing over the company Firma Landbell AG.



1

All used boxes are collected from partner companies (waste disposal contractor) at private customers (local household), sorted and properly utilized. The Involvement in a Dual Systems helps to save CO² Emissions.

Battery charging instruction

Installation of Remote Control Battery

1. Loosen the screw of battery cover by screwdriver and take out battery cover. (Pic .1)

into the battery box to the right polarity at the bottom of remote control. (Pic .2)


3. Install the battery cover and tighten the screw. (Pic .3)

2. Put four 1.5V AA non-rechargeable batteries (batteries need to be purchased separately)

Charging methods

ATTENTION:

Connect the battery port with USB charging port as the picture shows. Make sure the port be connected tightly and correctly. Then insert the USB charging plug into power adapter and perform charging.



Batteries shall be to the right polarity.

State of USB light:

- 1. The LED is lighting all the time when being connected.
- 2. The LED is flashing when charging.
- 3. The LED is off when battery is full of power.


Charging time: 3-4 hours When the battery is full of power,

please pull off USB wire in time.


(Pic .3)

Installation of setting battery in truck


1. Loosen screw of battery cover by screwdriver, twist the buckle and take out battery cover.(Pic .1)



2. Connect rechargeable battery with power port of truck, then put it into the battery box.(Pic .2)




3. Install the battery cover, tighten the screw and twist the buckle back.(Pic .3)



3

Operation of remote control



The match of R/C frequency and power on

This product is controlled by the frequency of 2.4GHz. When playing it at the first time, please turn on the power and wait for the automatically matching of frequency. The sound -"beeps" given by the product indicates that the frequency is matched successfully.



Control of light and sound

















The operation of front wheel


When the truck can't go straightly, please control the front wheel to the left or right lightly.

and press once more to turn it off.


















Operation of playing the truck

Forward



5

4

6