




BRUCE LEE

SLAM MAN



OWNERS MANUAL

WWW.BRUCELEEFITNESS.COM

TABLE OF CONTENTS

Important Safety Tips	page 3
User Information	page 4
Getting Started	page 5
Operating Instructions	page 6
Specifications & Parts	page 7
How To Choose Your Punches	page 8
Workout Routine Principles	page 9
Sample Workout Routine	page 10
Trouble Shooting	page 11

IMPORTANT SAFETY TIPS

Before starting this or any other exercise programme, consult your physician. Certain exercises, programmes and types of equipment may not be appropriate for persons over the age of 35 years, expectant mothers, or those with pre-existing health problems or balance impairments.

Read **ALL** instructions before using any fitness equipment.

Start out slowly and progress sensibly at a pace that is suitable for you.

Monitor your heart rate whilst you exercise and maintain your pulse within your target heart rate zone.

Do not over exert yourself with this or any other exercise programme. Listen to your body and respond to any reactions you may be having. Please ensure you distinguish between discomfort like fatigue, and pain which hurts. Should you experience any pain or tightness in your chest, an irregular heartbeat or shortness of breath, stop exercising immediately and consult your physician before continuing.

Stay hydrated, drinking plenty of water before, during and after your workout.

Set up your Bruce Lee Slam Man on an appropriate solid, flat surface with plenty of clearance space around it. Do not assemble or use on a wooden floor, please ensure the floor area is protected with a non-slip mat.

It is imperative to ensure the base of the Bruce Lee Slam Man is filled with approximately 100kg of dry sand to ensure stability.

Remove all jewellery and wear appropriate clothing when exercising which should be lightweight and comfortable. Wear athletic shoes and boxing/bag/MMA gloves when using the Bruce Lee Slam Man. **DO NOT** use this product with bare feet or unprotected hands.

The Bruce Lee Slam Man is not intended for use by children, please do not leave children unattended around this product.

Tunturi Fitness B.V. assumes no responsibility for personal injury or damage to property sustained by or through the use of this product.

USER INFORMATION

LIMITED WARRANTY

Tunturi B.V. warrants this product to be free from defects in workmanship and material, under normal use and service conditions, for a period of one year on all parts and components from the date of purchase. This warranty extends only to the original purchaser. Tunturi B.V.'s obligation under this Warranty is limited to replacing damaged or faulty parts at Tunturi B.V.'s option.

All returns must be pre-authorized by Tunturi. This warranty does not extend to any product or damage to a product caused by or attributable to freight damage, abuse, misuse, improper or abnormal usage, purchasers own repairs or for products used for commercial or rental purposes. No other warranty beyond that specifically set forth above is authorized by Tunturi.

Tunturi is not responsible or liable for indirect, special or consequential damages arising out of or in connection with the use or performance of the product or other damages with respect to any economic loss, loss of property, loss of revenues or profits, loss of enjoyments or use, costs of removal, installation or other consequential damages or whatsoever natures.

The warranty extended hereunder is in lieu of any and all other warranties and any implied warranties of merchantability or fitness for a particular purpose is limited in its scope and duration to the terms set forth herein.

Your statutory rights are not affected.

CARE & STORAGE

Your Bruce Lee Slam Man has been carefully designed to require minimum maintenance. However, to ensure this we recommend the following:

1. Keep your Slam Man clean by wiping sweat, dust or other residues off with a soft, clean dry cloth after every use.
2. Examine regularly for signs of damage or wear and tear.
3. Inspect and tighten parts before using the Slam Man.
4. Replace any defective components immediately and/or keep the machine out of use until repair.

IMPORTANT: This owners manual is the authoritative source of information about your Bruce Lee Slam Man. Please read it carefully, follow all the instructions and retain for future reference.

GETTING STARTED

The following instructions will prepare you to learn how to use your Bruce Lee Slam Man correctly:

Once your Bruce Lee Slam Man is assembled and the base filled with sand, make sure it is on a solid, stable surface with plenty of room around it.

Adjust your Bruce Lee Slam Man to the appropriate height, by loosening the brackets at the back and move the upper section up or down until you achieve a height similar to your own. When you are ready for another challenge, adjust the Bruce Lee Slam Man up or down for a taller or shorter opponent.

Remove all jewellery and put on boxing, bag or MMA gloves before you begin your workout.

OPERATING INSTRUCTIONS

PROGRAMME DESCRIPTION:

Eight lights are lit in a 15 count sequence depending upon the programme selected. Each routine will repeat the same sequence of lights for a specific routine at any level until interrupted, or until the time expires

FUNCTIONS:

1. TIME – From 0.00 – 99.59 minutes
2. PUNCHES – From 0 – 9999
3. LEVEL MODE – Level 1, Level 2, and Level 3 are shown by three LED lights in the middle on the right hand side
4. ROUTINE PROGRAMMES – I, II, III, IV, V (random). Five programmes are shown by Five LED lights in the middle on the left hand side

OPERATIONS:

1. Press any button to activate monitor.
2. Press MODE button to select 3 modes; Programme, Level and Timer. A flashing LED indicates the active mode.
3. In Programme Mode: Press up / down buttons to scroll to desired programme. There are five routines to choose from, I, II, III, IV and V.
4. Press MODE button to scroll to next mode.
In LEVEL MODE: Press up / down buttons to desired level of difficulty. There are three levels:
Level 1 – Beginner Programme
Lights are lit for 0.5 seconds; 15 light sequence repeats continuously until time expires or Start/Stop button is pressed.
Level 2 – Intermediate Programme
Lights are lit for 0.3 seconds; 15 light sequence repeats continuously until time expires or Start/Stop button is pressed.
Level 3 – Advanced Programme
Each light remains lit until punched. This level will keep score for you.
5. Press MODE button to scroll to next mode. Timer Mode. In Timer Mode; Press up / down buttons to select amount of time for routine. The timer will only increase or decrease by minutes, not seconds.
6. Press START/STOP button to begin 15 punch routine based on programme selected. Routine repeats until interrupted by Start/Stop button or countdown timer has expired.
7. At any time user may press up / down buttons to scroll through performance information, number of punches and time elapsed.
8. Press START/STOP button to pause current routine or to select new routine. Please follow the above steps from 2 through to 6.
9. Monitor shuts down automatically if no buttons are pressed for more than 60 seconds.
10. RESET: Press and hold MODE button for 4 seconds to reset computer.



KEEPING SCORE

After the timer starts or the game begins, press the down arrow button to automatically display the number of punches.


NOTE: The monitor will automatically shut down after more than 60 seconds of inactivity on the boxing Slam Man unit.

SPECIFICATIONS AND PARTS


Length: 46cm
Width: 42 cm
Height: Minimum 162cm
 Maximum 182cm

Approximate Product Weight:

Unfilled: 10kg
Filled: 120kg



HOW TO CHOOSE YOUR PUNCHES



WORKOUT ROUTINE PRINCIPLES

Your Bruce Lee Slam Man Workout will Consist of Three Phases

Warm Up

To prevent injury and maximise performance, we recommend you begin each workout with at least 5 minutes of gentle exercise that gradually increases your heart rate and warms your muscles. This can be done by practicing all the Slam Man workout movements at a slow tempo and easy range of motion.

Aerobic and Muscle Toning Workout

To maximise the health and fitness benefits that you seek, the warm up should be followed by 15–20 minutes of aerobic boxing, 2-3 times per week with your Bruce Lee Slam Man. Build up to this amount as your fitness levels improve and progress at a rate that is comfortable to you. As your fitness level increases you may want to gradually increase the length and intensity of your workout to a total of 30 minutes, most days of the week.

Once the basic workout is comfortable for you, interval training offers the opportunity for greater workout variety, increasing cardiovascular benefits and calorie burning. Interval training means alternating short periods between high intensity workouts (using the whole body), and lower intensity workouts (using upper body only). When performing at higher levels of intensity you will work at a level that is at the higher end of your target heart rate zone, and lower intensity at the lower end of your heart rate zone.

Monitor your heart rate throughout your workout, this will help determine the level of exertion that is safe and appropriate to you and serve as a good measure when monitoring your progress. There are three variables that will help control the intensity of your workout.

Speed – Choose from three different skill levels which are programmed into your Bruce Lee Slam Man. Start with Level 1, which will be the slowest speed, then work up to levels 2 and 3.

Lower Body Work – Adding footwork uses the larger leg muscles, and when performed simultaneously with upper body punches the intensity of your workout increases. To decrease intensity, perform the punches with NO legwork.

Type of Punch – As you learn correct punching techniques, you will also learn which punches to use on each of the Slam Man targets. Punches such as a 'Power Punch', or 'Upper Cut', require more effort than a punch such as a 'Jab'. Using different punches during your workout will vary the intensity.

Cool Down

At the end of your aerobic boxing workout, return to easy boxing movements (as described in the Warm Up), and slow down the range of motion and tempo. Gradually slow down to a complete stop, and complete your workout with gentle stretches. This allows your heart rate to drop slowly back to its normal resting rate.

SAMPLE WORKOUT ROUTINE

This sample routine will help you to learn the sequence of flashing lights used in Programme 1, and to practice a series of punches that could be used with this programme. Remember there are many ways you can sequence the punches in each programme. This sample workout will teach you one, 15 punch sequence. After you get comfortable with this routine you can use different punches whenever you like.

Begin with your left foot and shoulder forward, as if using the Orthodox Position, and follow the following sequence of punches.

NOTE:

Once you have mastered Programme 1 in the Orthodox Position, change sides to a Southpaw Position (right foot and shoulder facing forward, and reverse all of the left/right directions below:

	FLASHING LIGHT SEQUENCE	CORRESPONDING PUNCH
1.	Left Eye	Left Jab
2.	Right Eye	Right Power Punch
3.	Centre Abdomen	Left Jab
4.	Left Eye	Left Jab
5.	Left Eye	Left Jab
6.	Right Eye	Right Power Punch
7.	Left Eye	Left Jab
8.	Mouth	Right Power Punch
9.	Left Eye	Left Jab
10.	Left Eye	Left Jab
11.	Centre Abdomen	Right Power Punch
12.	Right Upper Rib	Right Upper Cut
13.	Centre Abdomen	Left Upper Cut
14.	Left Upper Rib	Right Upper Cut
15.	Mouth	Right Hook

TROUBLE SHOOTING

PROBLEM	POSSIBLE SOLUTION
LCD cannot display or does not clear	Make sure the batteries are installed correctly, or replace with new batteries
Monitor does not activate as signal is input	Make sure the 15 pin jack is connected correctly. Turn the switch to OFF, and then turn ON again
Static Electricity	If you generate static electricity during your workout it is best to keep your gloves on when you turn off the monitor
In Level 3, when throwing a punch more than one light goes out	Check the sensor, you may have adjusted it to be too sensitive

ORDERING REPLACEMENT PARTS

Replacement parts can be ordered by contacting our Customer Service Department

E mail: service.international@tunturi-fitness.com

When ordering replacement parts, please give the following information,

Model Number
Description of Parts
Part Number
Date of Purchase



BRUCE LEE

Supplied by;

Tunturi Fitness B.V.

www.tunturi-fitness.com

E mail: info@tunturi-fitness.com

BRUCE LEE® is a registered trademark of Bruce Lee Enterprises, LLC. The Bruce Lee name, image, likeness and all related indicia are intellectual property of Bruce Lee Enterprises, LLC. All Rights Reserved. www.brucelee.com